JVC

VIDEO CASSETTE RECORDER

HR-S9500U



S-VHS
Hi-Fi
VCR Plus+ 3 Cable Box Control
Easy Taping.
COMMERCIAL ADVANCE®
MOVIE ADVANCE™
Super VHS ET
TIME SCAN

INSTRUCTIONS

For Customer Use:
Enter below the Model No. and Serial No. which are located on the rear of cabinet. Retain this information for future reference.

Model No. _____

Serial No. _____

LPT0027-001B

Dear Customer,
Thank you for purchasing the JVC VHS video cassette recorder. Before use, please read the safety information and precautions contained in the following pages to ensure safe use of your new VCR.

CAUTIONS


CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK.
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:
TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

CAUTION:
This video cassette recorder should be used with AC 120V∿, 60Hz only.
To prevent electric shocks and fire hazards, DO NOT use any other power source.

CAUTION:
TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

ATTENTION:
POUR ÉVITER LES CHOCS ÉLECTRIQUES, INTRODUIRE LA LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU'AU FOND.

Note to CATV system installer:
This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

CAUTION:
Changes or modifications not approved by JVC could void user's authority to operate the equipment.

Failure to heed the following precautions may result in damage to the VCR, remote control or video cassette.

1. **DO NOT place the VCR . . .**
   ... in an environment prone to extreme temperatures or humidity.
   ... in direct sunlight.
   ... in a dusty environment.
   ... in an environment where strong magnetic fields are generated.
   ... on a surface that is unstable or subject to vibration.
2. **DO NOT block the VCR's ventilation openings.**
3. **DO NOT place heavy objects on the VCR or remote control.**
4. **DO NOT place anything which might spill on top of the VCR or remote control.**
5. **AVOID violent shocks to the VCR during transport.**

**MOISTURE CONDENSATION

Moisture in the air will condense on the VCR when you move it from a cold place to a warm place, or under extremely humid conditions—just as water droplets form on the surface of a glass filled with cold liquid. Moisture condensation on the head drum will cause damage to the tape. In conditions where condensation may occur, keep the VCR's power turned on for a few hours to let the moisture dry before inserting a tape.

**ABOUT HEAD CLEANING

Accumulation of dirt and other particles on the video heads may cause the playback picture to become blurred or interrupted. Be sure to contact your nearest JVC dealer if such troubles occur.

VCR Plus+C^3 and PlusCode are trademarks of Gemstar Development Corporation.
The VCR Plus+ system is manufactured under license from Gemstar Development Corporation.

DSS™ is an official trademark of DIRECTV, Inc., a unit of GM Hughes Electronics. PRIMESTAR is a registered service mark of Primestar Partners, L.P. DISH Network™ is a trademark of Echostar Communications Corporation.

MOVIE ADVANCE™ and COMMERCIAL ADVANCE® are trademarks of SRT, Inc. A Jerry Iggulden invention licensed in association with Arthur D. Little Enterprises, Inc.

- Cassettes marked "S-VHS" and "VHS" can be used with this video cassette recorder. However, S-VHS recordings are possible only with cassettes marked "S-VHS".
  By using S-VHS ET it is possible to record and play back with S-VHS picture quality on VHS cassettes with this VCR.
- As an ENERGY STAR® Partner, JVC has determined that this product or product model meets the ENERGY STAR® guidelines for energy efficiency.

IMPORTANT PRODUCT SAFETY INSTRUCTIONS

Electrical energy can perform many useful functions. But improper use can result in potential electrical shock or fire hazards. This product has been engineered and manufactured to assure your personal safety. In order not to defeat the built-in safeguards, observe the following basic rules for its installation, use and servicing.

ATTENTION:
Follow and obey all warnings and instructions marked on your product and its operating instructions. For your safety, please read all the safety and operating instructions before you operate this product and keep this booklet for future reference.

INSTALLATION

1. Grounding or Polarization

(A) Your product may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature.
If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

(B) Your product may be equipped with a 3-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature.
If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.

2. Power Sources

Operate your product only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. If your product is intended to operate from battery power, or other sources, refer to the operating instructions.

3. Overloading

Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

4. Power Cord Protection

Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

5. Ventilation

Slots and openings in the cabinet are provided for ventilation. To ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered.

- Do not block the openings by placing the product on a bed, sofa, rug or other similar surface.
- Do not place the product in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

6. Wall or Ceiling Mounting

The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

ANTENNA INSTALLATION INSTRUCTIONS

1. Outdoor Antenna Grounding

If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding connectors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

2. Lightning

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

3. Power Lines

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE, ANSI/NFPA 70


ANTENNA LEAD IN WIRE
GROUND CLAMP
ANTENNA DISCHARGE UNIT (NEC SECTION 810-20)
ELECTRIC SERVICE EQUIPMENT
GROUNDING CONDUCTORS (NEC SECTION 810-21)
GROUND CLAMPS
POWER SERVICE GROUNDING ELECTRODE SYSTEM (NEC ART 250. PART H)

NEC – NATIONAL ELECTRICAL CODE

USE

1. Accessories

To avoid personal injury:

- Do not place this product on an unstable cart, stand, tripod, bracket, or table. It may fall, causing serious injury to a child or adult, and serious damage to the product.
- Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with the product.
- Use a mounting accessory recommended by the manufacturer and follow the manufacturer's instructions for any mounting of the product.
- Do not try to roll a cart with small casters across thresholds or deep-pile carpets.

2. Product and Cart Combination

A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.

PORTABLE CART WARNING
(Symbol provided by RETAC)

3. Water and Moisture

Do not use this product near water—for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement, or near a swimming pool and the like.

4. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

5. Attachments

Do not use attachments not recommended by the manufacturer of this product as they may cause hazards.

6. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

7. Heat

The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

SERVICING

1. Servicing

If your product is not operating correctly or exhibits a marked change in performance and you are unable to restore normal operation by following the detailed procedure in its operating instructions, do not attempt to service it yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

2. Damage Requiring Service

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

a. When the power supply cord or plug is damaged.
b. If liquid has been spilled, or objects have fallen into the product.
c. If the product has been exposed to rain or water.
d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
e. If the product has been dropped or damaged in any way.
f. When the product exhibits a distinct change in performance—this indicates a need for service.

3. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

4. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in safe operating condition.

HOW TO USE THIS INSTRUCTION MANUAL

- All major sections and subsections are listed in the Table Of Contents on page 5. Use this when searching for information on a specific procedure or feature.
- The Index on pages 69–72 lists frequently-used terms, and the number of the page on which they are used or explained in the manual. This section also illustrates the controls and connections on the front and rear panel, the front display panel and the remote control.
- The ☞ mark signals a reference to another page for instructions or related information.
- Operation buttons necessary for the various procedures are clearly indicated through the use of illustrations at the beginning of each major section.

BEFORE YOU INSTALL YOUR NEW VCR . . .

. . . please read the sections/literature listed below.

- "Cautions" on page 2
- "Important Products Safety Instructions" on the previous pages

INSTALLING YOUR NEW VCR 6

Connections 6
Basic Connections 6
S-VIDEO Connection 7

INITIAL SETTINGS 8

Plug & Play 8
Language 10
Clock 11
Preparation 11
Semi-Auto 12
Manual 13
Tuner 14
Set Receivable Channels 14
Add Or Delete A Channel 15
Cable Box Control 16
Situate And Connect Controller 16
Set Cable Box Output Channel & Cable Box Brand 17
DBS Receiver Control 19
Situate And Connect Controller 19
Set DBS Receiver Output Channel & DBS Receiver Brand 20

SIMPLE PLAYBACK AND RECORDING 22

Simple Playback 22
Simple Recording 23

PLAYBACK AND RECORDING FEATURES 24

Playback Features 24
Still Picture/Frame-By-Frame Playback 24
Slow Motion (Pro-Slow*)/Reverse Slow Motion/ Reverse Motion Playback 24
High-Speed Search 24
High-Speed Search (JOG/SHUTTLE) 25
Variable-Speed Search/Reverse Motion Playback (JOG/SHUTTLE) 25
Still Picture/Frame-By-Frame Playback (JOG/SHUTTLE) 25
Slow Motion/Reverse Slow Motion (JOG/SHUTTLE) 25
Manual Tracking 26
Skip Search 26
Index Search 27
Instant ReView 27
Repeat Playback 27
Counter Reset 27
Tape Position Indicator 27
Next-Function Memory 27
Video Stabilizer 28
Superimpose 29
Select The Soundtrack 30
Movie Advance 31
Commercial Advance 32
AV COMPU LINK Playback 34
Digital R3 35
Digital TBC/NR 35
Active Video Calibration 36
Preparation 36
Recording 37
Playback 37
TimeScan 38
Variable-Speed Search/Reverse Motion Playback 38
TimeScan 39
TimeScan Audio 39

Recording Features 40
Record One Program While Watching Another 40
Display Elapsed Recording Time 40
Display Tape Remaining Time 40
S-VHS (Super VHS), S-VHS ET and VHS 41
Super VHS ET 42
Stereo And SAP (Second Audio Program) 43
To Record SAP Programs 43
Hi-Fi Audio Recording Level Control 44
Instant Timer Recording (ITR) 45

TIMER RECORDING 46

VCR Plus+ Timer Programming 46
VCR Plus+ Setup 48
Express Timer Programming 50
Check, Cancel And Revise Programs 52
Auto SP→EP Timer 53
Auto Timer 53

EDITING 54

Edit From A Camcorder 54
Edit To Or From Another VCR 56
Audio Dubbing 57
Insert Editing 58

SPECIAL FEATURES 60

TV Multi-Brand Remote Control 60
Cable Box Multi-Brand Remote Control 61
DBS Receiver Multi-Brand Remote Control 62
Control Two JVC VCRs 63
Child Lock 63

INFORMATION ON J TERMINAL 64

TROUBLESHOOTING 65

Power 65
Tape Transport 65
Playback 65
Recording 65
Timer Recording 66
Other Problems 67

QUESTIONS AND ANSWERS 68

Playback 68
Recording 68
Timer Recording 68

INDEX 69

List Of Terms 69
Front View 70
Rear View 71
Front Display Panel 71
Remote Control 72

SPECIFICATIONS 73

FOR SERVICING 74

WARRANTY 75

Connections



NOTES:

- *The VCR channel is the channel on the TV which will display the audio and video signals from the VCR. The VCR's CH3-CH4 switch, on the back of the VCR, sets the VCR channel to CH3 or CH4.*
- *The CH3–CH4 switch is preset to the CH3 position. Set to CH4 if CH3 is used for broadcasting in your area and set the channel on the TV to correspond to the VCR's CH3–CH4 switch setting.*
- *If you have connected your VCR to the TV using the RF connector, you may need to press the TV's CH UP and then CH DOWN when switching between the TV and VCR input modes, to maintain good picture quality.*
- *Even if you are using AV cables to connect your VCR to your TV, you must also connect it using the RF cable. This will ensure that you can record one show while watching another (☞ pg. 40).*
- *For full identification of the VCR's rear panel, refer to the Index (REAR VIEW☞ pg. 71).*

Basic Connections

1 CHECK CONTENTS

Make sure the package contains all of the accessories listed in "SPECIFICATIONS" (☞ pg. 73).

2 SITUATE VCR

Place the VCR on a stable, horizontal surface.

3 CONNECT VCR TO TV

The connection method you use depends on the type of TV you have.

RF Connection

- *To Connect To A TV With NO AV Input Terminals . . .*
  - **a–** Disconnect the TV antenna from the TV.
  - **b–** Connect the TV antenna cable to the ANTENNA IN jack on the rear of the VCR.
  - **c–** Connect the supplied RF cable between the TV OUT jack on the rear of the VCR and the TV's antenna terminal. Set TV on CH3 or CH4 corresponding to the CH3 – CH4 switch setting on the back of the VCR.

AV Connection

- *To Connect To A TV With AV Input Terminals . . .*
  - **a–** Connect the antenna, VCR and TV as shown in the illustration.
  - **b–** Connect an Audio/Video Cable between the AUDIO OUT and VIDEO OUT jacks on the rear of the VCR and the AV IN jacks on the TV. Set your TV in video input mode or A/V input mode. Refer to the TV Instruction Manual.

S-VIDEO Connection

- *If you have a TV with S-VIDEO input terminals, see "S-VIDEO Connection" on page 7.*

4 CONNECT VCR TO POWER SOURCE

Connect the power plug to an AC outlet.

- The clock and tuner channels will automatically be set when the antenna is connected and when the AC is first connected to the VCR (☞ pg. 8). (If "Auto" or "CH" is displayed on the front display panel before the VCR is powered on, the clock and tuner channels are being set automatically. Wait for the time to be displayed on the front display panel before powering on the VCR.)

5 FINAL PREPARATION FOR USE

Power on the VCR and if you have connected the VCR to the TV using the RF connector, select the VCR channel (3 or 4) by setting the switch on the rear of the VCR as shown in the illustration.
You can now perform simple playback (☞ pg. 22) or simple recording (☞ pg. 23).



NOTES:

- *To make the most of the Super VHS picture performance we recommend that you use the supplied S-VIDEO cable to connect your VCR to a TV with an S-VIDEO input connector.*
- *To operate the VCR with your TV using the S-VIDEO connection, set your TV to the AV mode using the TV's remote control.*
  *You can also use the **TV/VCR** button on the VCR's remote control to set your TV to the AV mode. (☞ pg. 60)*

S-VIDEO Connection

CONNECT VCR TO TV

a– Connect both the RF cable and the AV cables to the TV as explained in step **3** of "Basic Connections" (☞ pg. 6).

b– Connect the S-Video cable between the S-VIDEO OUT jack on the rear of the VCR and the S-VIDEO IN jack on the TV.

Plug & Play

Auto Clock Set/Auto Tuner Set

ATTENTION
If you use a cable box, Plug & Play will not function; set the clock and tuner channels manually. (☞ pg.11 – 15)



IMPORTANT
- Don't press any buttons on the VCR or remote while Plug & Play is in progress.
- If you perform Plug & Play successfully, there's no need to perform the Clock (☞ pg. 11) and Tuner (☞ pg. 14) procedures. If, however, you want to add or delete channels, refer to "Add Or Delete A Channel" on page 15.

The Plug & Play function sets the clock and tuner channels automatically when power is first connected to the VCR. The antenna cable must be connected for the Plug & Play function.

The time and date can be set automatically from clock setting data that is transmitted by one of the regular TV broadcast channels. We call this TV channel the "Host Channel" and it is a PBS channel in your area.

1 PLUG & PLAY SETUP

Connect the antenna cable to the VCR (☞ pg. 6). Then connect the VCR's power plug to an AC outlet. Do not power on the VCR. The clock and tuner channels will be set automatically.

NOTES:

- *Auto clock set is performed first. The auto clock set function scans all the channels received by your VCR to find the Host Channel and then sets the clock. "Auto" blinks on the front display panel during Auto clock set.*
- *Auto channel set is performed next. The auto channel set function scans all the channels that are receivable by your VCR. It then automatically assigns each receivable channels to the **CH▲▼** (+/–) buttons. It skips non-receivable channels. During auto channel set the channel numbers are displayed as they are scanned and set.*
- *When Plug & Play has been completed successfully the correct time is displayed.*
- *If an incorrect time or "– –:– –" appears on the display panel, see "What To Do If Plug & Play Has Failed" on next page.*

During Initial Auto Clock Set
"Auto" blinks.

During Auto Channel Set
The channel numbers are displayed as they are scanned and set.

Plug & Play Completed
The current time (including AM/PM) is displayed.

* If an incorrect time or "– –:– –" appears on the display panel, see "What To Do If Plug & Play Has Failed" on next page.

INFORMATION

- If "AUTO CLOCK" is set to "ON" at the Clock Set screen on page 12, the clock will be adjusted automatically by the host channel every hour on the hour (except for 11:00 PM, midnight, 1:00 AM and 2:00 AM) by the incoming PBS channel clock setting data. (This automatic clock adjustment can only be performed when the VCR's power is turned off. The clock will be adjusted on the hour based on the time displayed on the VCR, not on the actual real time.) The default setting of "AUTO CLOCK" is "ON".
- If the memory backup fails, because of a power outage or because the AC was removed from the VCR, Plug & Play will be performed when power is restored to the VCR.

What To Do If Plug & Play Has Failed

- If an incorrect time is displayed on the front display panel, you may be receiving the clock setting data of a PBS channel from an adjacent time zone, or an incorrect PBS channel from a cable TV system. In this case, perform the Semi-Auto (☞ pg. 12) or Manual Clock Set (☞ pg. 13) procedure. Auto channel set has already taken place and it need not be set again.
- If "- -:- -" appears on the display, your antenna cable may not be connected to the VCR or there may not be a Host PBS signal available in your area. Ensure that the antenna cable is connected correctly. Then power on and power off the VCR; the Plug & Play function will be automatically reactivated and "Auto" will be displayed on the VCR's front panel. If Plug & Play is not performed but the antenna cable is connected correctly, perform the Manual Clock Set procedure (☞ pg. 13). Auto channel set has not yet taken place, so please also perform the "Set Receivable Channels" procedure (☞ pg. 14).

Language

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





This VCR offers you the choice to view on-screen messages in English, Spanish or French (not including messages superimposed on the TV picture). Select the desired language using this procedure. The default setting is "ENGLISH".

1 TURN ON THE VCR

Press **POWER**.

2 ACCESS MAIN MENU SCREEN

Press **MENU**.

3 ACCESS INITIAL SET SCREEN

At the Main Menu screen, move the highlight bar (arrow) to "INITIAL SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

```
MAIN MENU

FUNCTION SET
TUNER SET
→ INITIAL SET
HI-FI REC LEVEL CTL

PRESS (▲,▼), THEN (OK)
PRESS (MENU) TO END
```

4 SELECT LANGUAGE

Move the highlight bar (arrow) to "LANGUAGE" by pressing **CH ▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷ to select the desired language.

```
INITIAL SET

CLOCK SET
→LANGUAGE          ENGLISH
GUIDE CHANNEL SET
CABLE BOX SET
DBS RECEIVER SET
JLIP ID NO. SET
SELECT WITH (▲,▼) AND (OK)
PRESS (MENU) TO END
```

5 RETURN TO NORMAL SCREEN

Press **MENU**.

Clock

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





Perform clock setting only if the clock has not been set correctly by the Plug & Play function or you use a cable box. Access the Clock Set screen to perform the Semi-Auto or Manual clock setting procedure. Each procedure starts from step **5**.
If you use a cable box, set the clock manually. (☞ pg. 13)

Preparation

1 TURN ON THE VCR

Press **POWER**.

2 ACCESS MAIN MENU SCREEN

Press **MENU**.

3 ACCESS INITIAL SET SCREEN

At the Main Menu screen, move the highlight bar (arrow) to "INITIAL SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

```
MAIN MENU

FUNCTION SET
TUNER SET
→ INITIAL SET
HI-FI REC LEVEL CTL

PRESS (▲,▼), THEN (OK)
PRESS (MENU) TO END
```

4 ACCESS CLOCK SET SCREEN

Move the highlight bar (arrow) at the Initial Set screen to "CLOCK SET" by pressing **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

```
INITIAL SET

→CLOCK SET
LANGUAGE          ENGLISH
GUIDE CHANNEL SET
CABLE BOX SET
DBS RECEIVER SET
JLIP ID NO. SET
SELECT WITH (▲,▼) AND (OK)
PRESS (MENU) TO END
```

- "CABLE BOX USERS SET CLOCK MANUALLY" appears on the screen for about 5 seconds, then the Clock Set screen appears.





Semi-Auto

You can change the Host Channel/D.S.T. /Time Zone setting manually.

5 SET AUTO CLOCK TO ON

At the Clock Set screen, press **OK** or **TIME SCAN** ▷ repeatedly to move the highlight bar to "AUTO CLOCK" and press **CH** ▲▼ or **TIME SCAN** △▽ to set to "ON".

CLOCK SET

TIME 1:00PM DATE 12/24 YEAR 98 THU
AUTO CLOCK : ON
HOST CH : AUTO (CATV)
D.S.T. : AUTO
TIME ZONE : AUTO
PRESS (▲,▼), THEN (OK)
PRESS (MENU) TO END

a– To select the Host Channel — go to step **6**
b– To select the D.S.T. mode — go to step **7**
c– To select the Time Zone — go to step **8**

NOTE:

The time that has been set previously will be erased when "AUTO CLOCK", "HOST CH", "D.S.T." or "TIME ZONE" setting is changed.

6 SELECT HOST CHANNEL

You can either select "AUTO" or enter a PBS channel number. Move the highlight bar to "HOST CH" by pressing **OK** or **TIME SCAN** ▷, then press **CH** ▲▼ or **TIME SCAN** △▽ to set to "AUTO" or the desired PBS channel number.

NOTE:

There are some PBS channels that do not transmit clock setting data.

7 SELECT D.S.T. MODE

You have three choices:
a– Select "AUTO" and the adjustment to your VCR's clock will be made according to the incoming signal from the host channel.
b– Select "ON" and the adjustment will be made based on the clock itself.
c– Select "OFF" if Daylight Saving Time does not apply to you.

Move the highlight bar to "D.S.T." by pressing **OK** or **TIME SCAN** ▷, then press **CH** ▲▼ or **TIME SCAN** △▽ to select the desired mode.

****AUTO DAYLIGHT SAVING TIME**

This function enables automatic adjustment of the VCR's clock at the start and end of Daylight Saving Time.
With Auto DST activated, . . .
. . . on the first Sunday of April at 2:00 AM, the clock is adjusted to 3:00 AM.
. . . on the last Sunday of October at 2:00 AM, the clock is adjusted to 1:00 AM.

8 SELECT TIME ZONE

You can select the time zone automatically or manually. Move the highlight bar to "TIME ZONE" by pressing **OK** or **TIME SCAN** ▷, then press **CH ▲▼** or **TIME SCAN** △▽ to select "AUTO" or the desired time zone.



NOTE:

*If an incorrect time is displayed by the Plug & Play function, you may be receiving the clock setting data of a PBS channel from an adjacent time zone or from an incorrect PBS channel from a cable TV system. If you selected "AUTO" for the host channel in step **6**, be sure to select the correct time zone manually.*

9 RETURN TO NORMAL SCREEN

Press **MENU**.

IMPORTANT
Turn the VCR off after performing the Semi-Auto Clock Set procedure. "Auto" will appear on the front display panel when the clock is being set. The current time will appear automatically when the clock is set.

Manual

5 SET TIME

Press **CH ▲▼** or **TIME SCAN** △▽ until the desired time appears, then press **OK** or **TIME SCAN** ▷.



- Press and hold **CH ▲▼** or **TIME SCAN** △▽ to change the time by 30-minute increments.
- When the time is entered manually, "AUTO CLOCK" will be automatically set to "OFF", and "HOST CH" and "TIME ZONE" will disappear.

6 SET DATE

Press **CH ▲▼** or **TIME SCAN** △▽ until the desired date appears, then press **OK** or **TIME SCAN** ▷.

- Press and hold **CH ▲▼** or **TIME SCAN** △▽ to change the date by 15-day increments.

7 SET YEAR

Press **CH ▲▼** or **TIME SCAN** △▽ until the desired year appears, then press **OK** or **TIME SCAN** ▷ twice.

8 SELECT D.S.T. MODE

Press **CH ▲▼** or **TIME SCAN** △▽ to select the desired mode.

a– Set to "ON" so that the adjustment to your VCR's clock will be made on the clock itself.
b– Set to "OFF" if Daylight Saving Time does not apply to you.

9 START CLOCK

Press **MENU** and normal screen appears.

To Make Corrections

Press **OK** or **TIME SCAN** ▷ until the item you want to change blinks, then press **CH ▲▼** or **TIME SCAN** △▽.

Tuner

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





INFORMATION
The VCR detects the band (TV or CATV) and selects the correct band automatically during Auto Channel Set. The selected band will be displayed on the right side of "BAND" on the Tuner Set screen.

Set Receivable Channels

1 TURN ON THE VCR

Press **POWER**.

2 ACCESS MAIN MENU SCREEN

Press **MENU**.

3 ACCESS TUNER SET SCREEN

Move the highlight bar (arrow) to "TUNER SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.



4 PERFORM AUTO CHANNEL SET

Move the highlight bar (arrow) to "AUTO CHANNEL SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.



- Receivable channels in your area are automatically assigned to the **CH▲▼** (**+/–**) buttons, and non-receivable channels are skipped.



NOTES:

- *At the end of Auto Channel Set, "SCAN COMPLETED" appears on screen.*
- *If the scan was unsuccessful, "SCAN COMPLETED–NO SIGNAL" appears on screen. Check the connections and start again.*

5 RETURN TO NORMAL SCREEN

Press **MENU**.





Add Or Delete A Channel

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS TUNER SET SCREEN

Move the highlight bar (arrow) to "TUNER SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

3 ACCESS MANUAL CHANNEL SET SCREEN

Move the highlight bar (arrow) to "MANUAL CHANNEL SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.



4 ADD OR SKIP DESIRED CHANNEL

Input the channel number using the **NUMBER** keys or by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷ to set to "ADD" or "SKIP" as required. Repeat for each channel you want to add or skip.



5 RETURN TO NORMAL SCREEN

Press **MENU**.

Cable Box Control

Suggested Location
Place the cable box on top of the VCR. Attach the VCR's Controller to the top of the VCR with the Controller's transmitter pointed towards the cable box's remote sensor.

ATTENTION:

The Controller can also control a DBS receiver. If both a cable box and a DBS receiver are used, position the controller so its signal reaches the remote control sensors of both the cable box and DBS receiver.





This procedure is required if you receive your TV channels through a cable box (descrambler). The Controller allows the VCR to automatically switch the cable box channel during timer-recording. The Controller is effective for recording shows that have been programmed using VCR Plus+ (☞ pg. 46) or Express Timer Programming (☞ pg. 50).

Situate And Connect Controller

1 SITUATE CONTROLLER

Place the Controller so that the path between its transmitter and the cable box's remote sensor is unobstructed.

2 ATTACH CONTROLLER

Fasten securely using the supplied adhesive strip.

3 CONNECT CABLE BOX TO VCR

The connection method depends on the type of cable box you have.

If your cable box has AUDIO and VIDEO OUT connectors . . .
. . . connect them to the AUDIO and VIDEO IN connectors on your VCR. Set the VCR to channel "L-1" for the rear AUDIO and VIDEO IN connectors, or channel "F-1" for the front AUDIO and VIDEO IN connectors to use the cable box.
If your cable box doesn't have AUDIO and VIDEO OUT connectors . . .
. . . connect the antenna output connector on the cable box to the ANTENNA IN connector on the rear of your VCR.
Set the VCR tuner to the same channel as the cable box RF output (see page 17 also).

NOTE:
When connecting your cable box refer to its instruction manual.

4 CONNECT CONTROLLER TO VCR

Connect to the CABLE BOX connector on your VCR.

About Your Cable Box

This VCR has two separate methods to control your Cable Box.

- *The VCR's Wireless Remote Control Unit can control your Cable Box.*
  This eliminates the need for a separate Cable Box Remote Control Unit.
- *The VCR's Controller can also control your Cable Box.*
  This allows the VCR to change your Cable Box's channel number during timer recording.

Each method must be set up separately. To set up the VCR's Remote Control unit, refer to page 61. To set up the Controller go to page 17.

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





Set Cable Box Output Channel & Cable Box Brand

1 TURN ON CABLE BOX

Select a channel other than channel 9 on your cable box.

2 TURN ON THE VCR

Press **POWER**.

3 ACCESS MAIN MENU SCREEN

Press **MENU**.

4 ACCESS INITIAL SET SCREEN

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "INITIAL SET", then press **OK** or **TIME SCAN** ▷.

5 ACCESS CABLE BOX SET SCREEN

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "CABLE BOX SET", then press **OK** or **TIME SCAN** ▷.



6 SELECT CABLE BOX OUTPUT CHANNEL

Your selection depends on how your cable box is connected to your VCR.



If your cable box is connected to your VCR using an RF connection . . .

. . . press **CH ▲▼** or **TIME SCAN** △▽ until the channel number representing the cable box's output (CH2 – CH9) appears on the screen.

If your cable box is connected to your VCR's FRONT AUDIO/VIDEO IN connectors . . .

. . . press **CH ▲▼** or **TIME SCAN** △▽ until "ON F-1 (FRONT)" appears on the screen.

If your cable box is connected to your VCR's REAR AUDIO/VIDEO IN connectors . . .

. . . press **CH ▲▼** or **TIME SCAN** △▽ until "ON L-1 (REAR)" appears on the screen.

CONTINUED ON NEXT PAGE





INFORMATION

When the VCR's clock has not been set (with AUTO CLOCK set to ON), if you press **OK** in step **7**, "CABLE BOX USERS SET CLOCK MANUALLY" will be displayed on the screen for about 5 seconds, then the Clock Set screen will appear; perform the manual clock setting procedure on page 13. If you press **MENU** after the clock has been set, the Cable Box Brand Set screen appears.

NOTES:

- *Although the supplied Controller is compatible with many different cable box brands, it is possible that it will not work with your cable box.*
- *If your cable box doesn't respond to any code between 1 and 25, you can't use the Controller to change cable box channels. In this case, make sure to leave the cable box turned on and tuned to the proper channel before the scheduled start of timer recording.*
  Please contact your cable company about the possibility of exchanging your current cable box with one that is compatible with your VCR.
- *The VCR can only change the cable box channel through the Controller during timer recording.*
- *If your cable box is one that can't be operated with a remote control (because it has no remote sensor), you can't use the Controller to change its channels. Make sure to leave the cable box turned on and tuned to the proper channel before the scheduled start of timer recording.*
- *If the VCR's memory backup expires because of a power failure, set the cable box output channel and brand again.*
- *If you are unable to set the Controller, please contact JVC toll free at 1-800-252-5722.*

7 ACCESS CABLE BOX BRAND SET SCREEN

Press **OK.**

8 ENTER CABLE BOX BRAND

Press the appropriate **NUMBER** keys to enter the Cable Box Code from the CABLE BOX BRAND LIST shown below, then press **OK**.



- If the cable box's channel changes to 9, setting is complete. Press **OK** and "CABLE BOX CONTROL IS ON" appears on the screen for about 5 seconds, then it returns to the normal screen.
- If the cable box's channel does not change to 9, press **CH ▲▼** or **TIME SCAN △▽** to move the highlight bar (arrow) to "NO", then press **OK**. By entering another code, repeat step **8** until the cable box's channel changes to 9.
- If the channel does not change after going through all the code numbers listed for your model of cable box, then try all the other numbers between 1 and 25.

CABLE BOX BRAND LIST

BRAND	CODE
ARCHER	1, 5, 17
CABLETENNA	1, 17
CABLEVIEW	15, 16, 17, 21, 25
CITIZEN	15, 16, 17, 21, 25
CURTIS	2
DIAMOND	1, 17
EASTERN	19
GC BRAND	15, 16, 17, 21, 25
GEMINI	15
GENERAL INSTRUMENTS	1, 4, 6, 11, 12, 15
HAMLIN	10, 18, 19, 23
JASCO	15
JERROLD	1, 4, 6, 11, 12, 15
NOVAVISION	2
OAK	7, 20
PANASONIC	13, 14
PULSER	15, 16, 17, 21, 25
RCA	13, 14
REGAL	10, 18, 19, 23
REGENCY	19
REMBRANDT	1, 16, 17
SAMSUNG	5, 16, 24
SCIENTIFIC ATLANTA	2
SIGMA	7, 20
SL MARX	5, 16, 17, 24, 25
SPRUCER	13, 14
STARGATE	5, 15, 16, 17, 21, 24, 25
TELEVIEW	5, 16, 24
TOCOM	1, 4, 16
UNIKA	1, 17
UNIVERSAL	16, 17, 25
VIDEOWAY	3, 9, 22
ZENITH	3, 9, 22

DBS Receiver Control

Suggested Location
Place the DBS (Direct Broadcast Satellite) receiver on top of the VCR. Attach the VCR's Controller to the top of the VCR with the Controller's transmitter pointed towards the DBS receiver's remote sensor.

ATTTNTION:

The Controller can also control a cable box. If both a DBS receiver and a cable box are used, position the controller so its signal reaches the remote control sensors of both the DBS receiver and cable box.





About Your DBS Receiver

This VCR has two separate methods to control your DBS Receiver.

- *The VCR's Wireless Remote Control Unit can control your DBS Receiver.*
  This eliminates the need for a separate DBS Receiver Remote Control Unit.
- *The VCR's Controller can also control your DBS Receiver.*
  This allows the VCR to change your DBS receiver's channel number during timer recording.

Each method must be set up separately. To set up the VCR's Remote Control unit, refer to page 62. To set up the Controller go to page 20.

The following procedure is required if you receive satellite channels through a DBS (Direct Broadcast Satellite) Receiver. The Controller allows the VCR to automatically switch the DBS Receiver's channels during timer recording.

NOTES:

- *The VCR can automatically change the DBS Receiver channels using the controller when the VCR has been programmed using Express Timer Programming (☞ pg. 50).*
  Because satellite programming does not use PlusCode; the Controller can not change the DBS Receiver channels during VCR Plus+ Timer Recording.
- *If a cable box is also used it is recommended that you connect the DBS receiver to your VCR's A/V inputs and the cable box to your VCR's antenna input.*

Situate And Connect Controller

1 SITUATE CONTROLLER

Place the Controller so that the path between its transmitter and the DBS receiver's remote sensor is unobstructed.

2 ATTACH CONTROLLER

Fasten securely using the supplied adhesive strips.

3 CONNECT DBS RECEIVER TO VCR

The connection method depends on the type of DBS receiver you have.

If your DBS receiver has AUDIO and VIDEO OUT connectors . . .
. . . connect them to the AUDIO and VIDEO IN connectors on your VCR. Set the VCR to channel "L-1" for the rear AUDIO and VIDEO IN connectors, or channel "F-1" for the front AUDIO and VIDEO IN connectors to use the DBS receiver.
If your DBS receiver doesn't have AUDIO and VIDEO OUT connectors . . .
. . . connect the antenna output connector on the DBS receiver to the ANTENNA IN connector on the rear of your VCR.
Set the VCR's tuner to the same channel as the DBS receiver's RF output. (See page 20 also.)

NOTE:

When connecting your DBS receiver refer to its instruction manual.

4 CONNECT CONTROLLER TO VCR

Connect to the CABLE BOX connector on your VCR.

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





Set DBS Receiver Output Channel & DBS Receiver Brand

1 TURN ON DBS RECEIVER

Select a channel other than channel 55, 100 or 205 on your DBS receiver.

2 TURN ON THE VCR

Press **POWER**.

- Set the VCR to the channel (3 or 4 or F-1 or L-1) on which the signals from the DBS receiver are received.

3 ACCESS MAIN MENU SCREEN

Press **MENU**.

4 ACCESS INITIAL SET SCREEN

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "INITIAL SET", then press **OK** or **TIME SCAN** ▷.

5 ACCESS DBS RECEIVER SET SCREEN

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "DBS RECEIVER SET", then press **OK** or **TIME SCAN** ▷.



6 SELECT DBS RECEIVER OUTPUT CHANNEL

Your selection depends on how your DBS receiver is connected to your VCR.



If your DBS receiver is connected to your VCR using an RF connection . . .

. . . press **CH ▲▼** or **TIME SCAN** △▽ until the channel number representing the DBS receiver's output (CH3 – CH4) appears on the screen.

If your DBS receiver is connected to your VCR's FRONT AUDIO/VIDEO IN connectors . . .

. . . press **CH ▲▼** or **TIME SCAN** △▽ until "ON F-1 (FRONT)" appears on the screen.

If your DBS receiver is connected to your VCR's REAR AUDIO/VIDEO IN connectors . . .

. . . press **CH ▲▼** or **TIME SCAN** △▽ until "ON L-1 (REAR)" appears on the screen.





7 ACCESS DBS RECEIVER BRAND SET SCREEN

Press **OK.**

8 SET DBS RECEIVER BRAND

Press the appropriate **NUMBER** keys to enter the DBS Receiver Code from the following list, then press **OK**.



BRAND	CODE
JVC (DISH Network)	51
ECHOSTAR (DISH Network)	51
PRIMESTAR	50
SONY (DSS)	41
RCA (DSS)	40

- After **OK** is pressed, the program currently received through the DBS receiver will appear for about 10 seconds.
- If the DBS receiver's channel changes to the channel listed below for your brand of DBS receiver, setting is complete. Press **OK** and "DBS RECEIVER CONTROL IS ON" appears on the screen for about 5 seconds, then it returns to the normal screen.

  JVC → 100
  ECHOSTAR → 100
  PRIMESTAR → 55
  SONY → 205
  RCA → 205

- If the DBS receiver's channel does not change as shown above, press **CH ▲▼** or **TIME SCAN △▽** to move the highlight bar (arrow) to "NO", then press **OK**. Re-enter the correct code.

NOTES:

- *It is possible that the Controller will not work with all types of DBS receiver.*
- *If your DBS receiver doesn't respond to the code, you can't use the Controller to change satellite channels. In this case, make sure to leave the DBS receiver turned on and tuned to the proper channel before the scheduled start of timer recording.*
- *The VCR can only change the satellite channel through the Controller during timer recording.*
- *If your DBS receiver is one that can't be operated with a remote control (because it has no remote sensor), you can't use the Controller to change its channels. Make sure to leave the DBS receiver turned on and tuned to the proper channel before the scheduled start of timer recording.*
- *If you are unable to set the Controller, please contact JVC toll free at 1-800-252-5722.*

Simple Playback

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





1 LOAD A CASSETTE

Make sure the window side is up, the rear label side is facing you and the arrow on the front of the cassette is pointing towards the VCR. Don't apply too much pressure when inserting.

- The VCR's power comes on automatically.
- The counter is automatically reset to "0:00:00".
- If the cassette's record safety tab has been removed, playback begins automatically.

2 FIND PROGRAM START POINT

If the tape is advanced past the start point, press **REW**. To go forward, press **FF**.

3 START PLAYBACK

Press **PLAY**. "VIDEO CALIBRATION" appears on the screen (when VIDEO CALIBRATION is set to "ON" ☞ pg. 36).

4 STOP PLAYBACK

Press **STOP** or **STOP/EJECT**. Then press **STOP/EJECT** to remove the cassette.

Usable cassettes

Full-Size VHS
T-30 (ST-30**)
T-60 (ST-60**)
T-90
T-120 (ST-120**)
T-160 (ST-160**)
ST-210**

Compact VHS*
TC-20 (ST-C20**)
TC-30 (ST-C30**)
TC-40 (ST-C40**)



* Compact VHS camcorder recordings can be played on this video recorder. Simply place the recorded cassette into a VHS Cassette Adapter and it can be used just like any full-sized VHS cassette.

** This VCR can record on regular VHS and Super VHS cassettes. While only VHS signals can be recorded on regular VHS cassettes*, both VHS and Super VHS signals can be recorded and played back using Super VHS cassettes.

** By using S-VHS ET it is possible to record and play back with S-VHS picture quality on VHS cassettes with this VCR.*

Simple Recording

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





1 LOAD A CASSETTE

Make sure the record safety tab is intact. If not, cover the hole with adhesive tape before inserting the cassette.

2 SELECT RECORDING CHANNEL

Press **CH▲▼ (+/–)**. Or press the appropriate **NUMBER** keys, then press **ENTER**. (The channel changes after a few seconds whether you press **ENTER** or not.)

- If you use the RF connection, by pressing the **TV/VCR** button, select VCR mode to view the program to be recorded.

3 SET TAPE SPEED

Press **SP/EP** to set the recording speed.

4 START RECORDING

Press and hold **REC** and press **PLAY** on the remote control, or press **REC** on the VCR's front panel.

Video Calibration takes place at the beginning of both the first SP and the first EP recording after inserting the cassette (when Video Calibration is set to "ON", ☞ pg. 36).

5 PAUSE/RESUME RECORDING

Press **PAUSE**. Press **PLAY** to resume recording.

- During record pause, you can change the recording channel by using the **CH▲▼ (+/–)** buttons or **NUMBER** keys.

Video Calibration will not take place if the tape speed is changed while in record pause mode.

6 STOP RECORDING

Press **STOP** or **STOP/EJECT**. Then press **STOP/EJECT** to remove the cassette.

Accidental erasure prevention

- To prevent accidental recording on a recorded cassette, remove its record safety tab.
  To record on it later, cover the hole with adhesive tape.



Playback Features





High-Speed Search

1

ACTIVATE HIGH-SPEED SEARCH

During playback or still, press **FF** for forward high-speed search, or **REW** for reverse high-speed search.

- The search speed is 7 times normal playback speed with SP recordings, and 21 times normal with EP recordings.
- TimeScan will be automatically engaged during high-speed search with an SP-recorded tape.
- If the tape speed changes from SP to EP during high-speed search the TimeScan mode will change to EP search mode.
- Press **TIME SCAN** for the opposite direction during high-speed search of an EP-recorded tape to change to 7x TimeScan search. (☞ pg. 38)

To resume normal playback, press **PLAY**.

NOTE:

*For short searches, during playback or still, press and hold **FF** or **REW** for over 2 seconds. When released, normal playback resumes.*

Still Picture/Frame-By-Frame Playback

1

PAUSE DURING PLAYBACK

Press **PAUSE**.

- During still picture, the normal (mono) sound from the previous 3 seconds (approx.) will be played back repeatedly (provided there was at least 6 seconds of normal playback prior to engaging the still picture mode).
- "TIMESCAN AUDIO" must be set to "ON", or the sound will not be heard (☞ pg. 39).

2

ACTIVATE FRAME-BY-FRAME PLAYBACK

Press **PAUSE** repeatedly to advance one frame at a time.

OR

Press **TIME SCAN ►►I** repeatedly for forward frame-by-frame playback or **TIME SCAN I◄◄** repeatedly for reverse frame-by-frame playback.

To resume normal playback, press **PLAY**.

Slow Motion (Pro-Slow*)/ Reverse Slow Motion/Reverse Motion Playback

* Smooth slow motion delivering an uninterrupted moving image without distortion.

1

ACTIVATE SLOW-MOTION PLAYBACK

For hands-free slow-motion, press **TIME SCAN I◄◄** during playback to decrease speed in the forward direction. Continue to press **TIME SCAN I◄◄** to select the reverse slow motion, reverse play and reverse search modes.

OR

During still picture, press and hold **TIME SCAN ►►I** for forward slow motion, or press and hold **TIME SCAN I◄◄** for reverse slow motion. Release to return to still picture.

To resume normal playback, press **PLAY**.

Refer to the chart on page 39 for the Play, Slow Motion and Search speeds that are selected using the **TIME SCAN** buttons.



You can also use the remote control's **JOG** dial/**SHUTTLE** ring for the operations described on this page. First press the **JOG/SHUTTLE** button on the remote control so that the button lights up before use. Refer to the **SHUTTLE** ring illustration below as you read the procedures.
NOTE: The operations by the **JOG** dial/**SHUTTLE** ring do not include TimeScan.



Shuttle Ring Modes

Forward search	: 3 steps
Normal playback	
Slow motion	: 2 steps
Reverse slow motion	: 2 steps
Reverse playback	
Reverse search	: 3 steps

High-Speed Search (JOG/SHUTTLE)

1 ACTIVATE HIGH-SPEED SEARCH

During playback or still, turn the **SHUTTLE** ring all the way to the right for forward high-speed search, or to the left for reverse high-speed search. By releasing **SHUTTLE** still picture playback is selected.

- For forward high-speed search, turn the **SHUTTLE** ring all the way to the right and release it within 1 second.
- For reverse high-speed search, turn the **SHUTTLE** ring all the way to the left and release it within 1 second.

To resume normal playback, press **PLAY**.

Variable-Speed Search/ Reverse Motion Playback (JOG/SHUTTLE)

1 ACTIVATE VARIABLE-SPEED SEARCH

During playback or still, turn the **SHUTTLE** ring to the right for forward variable-speed search, or to the left for reverse variable-speed search.

To resume normal playback, press **PLAY**.

Still Picture/Frame-By-Frame Playback (JOG/SHUTTLE)

1 PAUSE DURING PLAYBACK

Press **PAUSE**.

2 ACTIVATE FRAME-BY-FRAME PLAYBACK

Turn the **JOG** dial to the right for forward frame-by-frame playback, or to the left for reverse frame-by-frame playback.

To resume normal playback, press **PLAY**.

Slow Motion/Reverse Slow Motion (JOG/SHUTTLE)

1 ACTIVATE SLOW-MOTION PLAYBACK

During playback or still picture, turn the **SHUTTLE** ring to the right for forward slow motion, or to the left for reverse slow motion.

To resume normal playback, press **PLAY**.





Manual Tracking

Once playback begins, the VCR's automatic tracking function is engaged. If tracking noise appears in the picture, you can override this and make the adjustment manually.

1 ENGAGE MANUAL TRACKING MODE

During playback, press the **CH▲** and **▼** buttons on the VCR's front panel simultaneously to cancel the automatic tracking mode and enable manual tracking adjust.

2 ADJUST MANUAL TRACKING

Press **CH ▲ (+)** or **▼ (–)** on the VCR's front panel or remote. Press briefly for fine adjust, or press and hold for coarse adjust. Watch the screen and continue adjusting until optimum picture and sound quality are achieved.

3 RE-ENGAGE AUTOMATIC TRACKING

Press the **CH▲** and **▼** buttons on the VCR's front panel simultaneously.

- When automatic tracking is re-engaged, Video Calibration is automatically activated.

NOTES:

- *To obtain a noiseless still picture it may be necessary to adjust tracking in slow playback and then engage Pause.*
- *Manual tracking is possible during hands-free slow-motion. During hands-free slow-motion playback, simply press **CH ▲** (+) or ▼ (–) on the VCR's front panel or remote to adjust tracking.*

Skip Search

1 SKIP OVER UNWANTED SECTIONS

Press **SKIP SEARCH** 1 to 4 times during playback, with "CA PLAYBACK" set to "OFF" (☞ pg. 33). Each press initiates a 30-second period of fast-motion playback. Normal playback resumes automatically.

NOTES:

- *To return to normal playback during a Skip Search, press **PLAY.***
- *When **SKIP SEARCH** is pressed during playback of a pre-recorded tape or a tape with the safety tab removed, the Skip Menu is displayed (☞ pag. 31). When this menu is displayed, select "SKIP SEARCH" to select the skip search function.*

Index Search

Index codes are placed on the tape at the start of each recording. You can find and automatically play back from the start of any recording using the Index Search function.

1 START SEARCH

While the tape is stopped, press **TIME SCAN** ⏮ or ⏭.

2 ACCESS DISTANT CODE

To access a recording 2–9 index codes away, press **TIME SCAN** ⏮ or ⏭ repeatedly until the correct number is displayed on screen (only if "SUPERIMPOSE" is set to "ON" (☞ pg. 29). Playback begins automatically when the desired recording is located.

- If necessary press **REW** or **FF** when play starts to search visually to find the very beginning of the desired program.

NOTE:

An index code is not placed on the tape when recording is paused and then resumed.

Instant ReView

At the press of a button, you can power up your VCR, rewind the tape and begin viewing the most recently recorded or timer-recorded program.

1 ACTIVATE INSTANT REVIEW

After ensuring that the Timer mode is disengaged, press **REVIEW**.

- The power comes on and the VCR rewinds to the index code indicating the start of the last timer-recorded program, then begins playback automatically.
- You can access a program 2–9 index codes away from the current position on the tape. If, for example, you have 5 programs recorded and you want to watch the third one, press **REVIEW** three times.
- If necessary press **REW** or **FF** when play starts to search visually to find the very beginning of the desired program.
- If the tape is already rewound when **REVIEW** is pressed, it will play the tape from the beginning. It will not fast forward to an index code.
- The Instant Review function will also operate if the VCR's power is on.

Repeat Playback

1 START REPEAT

Press and hold **PLAY** (until " ▷ " blinks on the front display panel) during playback, then release.

- The entire tape is played back 50 times.

2 STOP REPEAT

To stop, press **STOP** at any time.

NOTE:

*Pressing **PLAY**, **REW**, **FF**, **PAUSE** or **TIME SCAN** ⏮ or ⏭ also stops Repeat Playback.*

Counter Reset

1 RESET COUNTER TO ZERO

Press **C.RESET**.

NOTE:

*By pressing the **DISPLAY** button, you can change the display to show the counter reading, channel number or clock time. (Channel number is not displayed during playback.)*

Tape Position Indicator

The Tape position indicator appears on screen when, from the stop mode, you press **FF**, **REW**, or perform an Index Search or Instant ReView. The position of " ■ " in relation to "B" (Beginning) or "E" (End) shows you where you are on the tape.



NOTES:

- *"SUPERIMPOSE" must be set to "ON", or the indicator will not appear (☞ pg. 29).*
- *It may take a few seconds for the Tape Position Indicator to be displayed.*

Next-Function Memory

The Next Function Memory "tells" the VCR what to do after rewinding. Before continuing, ensure that the VCR is in stop mode.

a– For Automatic Start Of Playback After Tape Rewind . . .
. . . press **REW**, then press **PLAY** within 2 seconds.
b– For Automatic Power Off After Tape Rewind . . .
. . . press **REW**, then press **POWER** within 2 seconds.
c– For Automatic Timer Standby After Tape Rewind . . .
. . . press **REW**, then press **TIMER** within 2 seconds.

NOTE:

It is not possible to select the Automatic Timer functions if the cassette's record safety tab is removed.





Video Stabilizer

By activating the Video Stabilizer you can correct vertical vibrations in the picture when playing back unstable EP recordings that were made on another VCR. When this function is set to "ON", vertical vibration will be automatically corrected.
*The default setting is "OFF".

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.



3 ACTIVATE VIDEO STABILIZER

Move the highlight bar (arrow) to "VIDEO STABILIZER" by pressing **CH ▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷ to set to "ON".



4 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTES:

- *Regardless of the setting, this function has no effect with SP recordings, during recording and during special-effects playback.*
- *When you finish viewing the tape, be sure to set it back to "OFF".*





Superimpose

This function, switchable between ON and OFF, determines whether or not operational indicators will appear on screen.

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

3 SELECT SUPERIMPOSE SET MODE

Move the highlight bar (arrow) to "SUPERIMPOSE" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷ to select the desired mode:

a– Select "ON" if you want the superimposed operational indications on the TV screen.

b– Select "OFF" if you do not want the superimposed operational indications on the screen.

FUNCTION	
AUTO TIMER	OFF
→SUPERIMPOSE	ON
AUTO SP→EP TIMER	OFF
DIGITAL R3	ON
VIDEO STABILIZER	OFF
2ND AUDIO RECORD	OFF
NEXT PAGE	
SELECT WITH (▲,▼) AND (OK)	
PRESS (MENU) TO END	

4 RETURN TO NORMAL SCREEN

Press **MENU**.

To recall an indication

1 Press **OSD**.
- All indications corresponding to the current status are displayed for 5 seconds. After that, the counter information and RECORD/PAUSE if in the Record Pause mode, are left displayed on the screen.

2 Press **OSD** again to clear the display.

NOTES:

- *If you engage the Record Pause mode, RECORD/PAUSE is displayed regardless of the Superimpose mode setting.*
- *If you select a channel on which no signal is received, the channel number is displayed regardless of the Superimpose mode setting.*

The superimposed indication on the TV screen tells you what the VCR is doing.



Tuned-in channel or AUX(iliary) mode
When the channel is changed, the new channel is displayed on the screen for 5 seconds.

Clock time

Stereo program indication

Second Audio Program indication

Tape position indicator

Audio mode indications

Counter reading
Switchable to the tape remaining time display

Operation mode
When the operation mode is changed, the new mode is displayed — RECORD (5 sec.), PLAY (5 sec.), FF/REW (5 sec. when engaged from Stop mode), RECORD PAUSE (for as long as Pause is engaged), and ITR *:** (5 sec.).

Tape speed indication

"Cassette Loaded" mark
When a cassette is loaded, the mark is displayed for 5 seconds. It blinks when the VCR's EJECT button is pushed.

INDEX indication





You can also select the soundtrack by simply pressing the remote control's **AUDIO MONITOR** button as follows:

Hi-Fi → Hi-Fi L → Hi-Fi R → Normal → Mix → Hi-Fi

Select The Soundtrack

Your VCR can record two soundtracks simultaneously (Normal and Hi-Fi) and play back the selected one, or both together. Or, when viewing a pre-recorded tape that contains two separate Hi-Fi audio programs, you can choose to listen to either one by selecting either "Hi-Fi L" or "Hi-Fi R" in step **3**.

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

3 SELECT AUDIO MONITOR SET MODE

Move the highlight bar (arrow) to "AUDIO MONITOR" by pressing **CH ▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷ to select the desired mode:

a– Hi-Fi
b– Hi-Fi L
c– Hi-Fi R
d– Normal
e– Mix



4 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTES:

- *If the tape being played back has no Hi-Fi soundtrack, the Normal soundtrack will be heard no matter what choice you make in step **3**.*
- *If RF connection is used for TV, even if Hi-Fi audio monitor is selected the sound will be mono and will be reproduced in both loudspeakers.*



ATTENTION

Movie Advance and Movie Advance (Preview) works only on prerecorded cassettes that have been recorded in the SP mode, and have no safety tab. If the VCR detects the EP mode after you press **OK** in step **4**, the following screen appears.



Skip Search will work for prerecorded EP tapes.

When "MOVIE ADVANCE" is selected...
- If you want to stop searching for the start of the movie, simply press **SKIP SEARCH** or **STOP**.

When "MOVIE ADVANCE (PREVIEW)" is selected...
- If **SKIP SEARCH** was inadvertently pressed, press it again to resume normal playback.
- While the VCR is searching for the next preview, if you see a preview you wish to view, press **SKIP SEARCH** and the VCR will immediately go to the start of that preview.
- If the VCR starts to reverse to a preview you do not wish to view, press **SKIP SEARCH** to initiate searching to the next preview.

NOTES:

- *Normally there is a period of black and no audio at the beginning and end of previews. The Movie Advance feature detects those parts where the picture fades to black and the audio fades to silence, and initiates fast-motion to skip over the detected previews.*
- *Some previews may not be detected and Movie Advance may not work properly.*
- *The setting you selected in step **3** remains in effect until the cassette is ejected.*
- *"MOVIE ADVANCE (PREVIEW)" does not use TimeScan when searching for the next preview.*

Patents Pending

Movie Advance

This feature helps you locate certain parts of prerecorded movies (rented or purchased) and works in two ways.
- You can go to the beginning of the movie, skipping over all previews.
- You can fast-motion the tape to the beginning of the next preview, so you can skip over previews one by one.

1 LOAD A CASSETTE

Insert a cassette that has a prerecorded movie (rented or purchased), with no safety tab, into the VCR. Playback begins automatically.

2 ACCESS SKIP MENU SCREEN

Press **SKIP SEARCH**.

3 SELECT MODE

Press **CH ▲▼** or **TIME SCAN △▽** to move the highlight bar (arrow) to your choice.



a– Select "MOVIE ADVANCE" if you want to advance directly to the beginning of the movie.

b– Select "MOVIE ADVANCE (PREVIEW)" if you want to advance to the next preview.

c– Select "SKIP SEARCH*" if you do not want to perform Movie Advance, then press **OK** to go back to the normal screen. Pressing **SKIP SEARCH** activates the Skip Search function (☞ pg. 26).

** If "CA PLAYBACK" is set to "AUTO" or "MANUAL" (☞ pg. 33), "COMMERCIAL ADVANCE" will be displayed on the screen instead of "SKIP SEARCH".*

4 PERFORM MOVIE ADVANCE

a– If you selected "MOVIE ADVANCE" in step **3** and press **OK**, the following screen will appear with a blue background. The VCR will rewind the beginning of the tape, then will fast-motion to the beginning of the movie. "READY" will appear and blink when the beginning of the movie is detected and the Stop mode will be engaged. Press **PLAY** to view the movie.



b– If you selected "MOVIE ADVANCE (PREVIEW)" in step **3** and press **OK**, the VCR will fast-motion to the beginning of the next preview and normal playback will resume when it is detected.
Each press of **SKIP SEARCH** fast-motions to the beginning of the next preview, thereby skipping over one preview each time.
The tape will forward-search a little past the start of the next preview, then will reverse-serach to the beginning of the preview and start playback.

Commercial Advance

Your VCR is eqipped with the Commercial Advance feature, which can automatically fast-motion the tape during playback to skip over previously recorded TV commercials.

Commercial Advance works as follows:

1 When recording is finished, the following display will appear on the screen and the VCR's front display panel.

* In case of timer recording, these displays will appear when all the preset programs are recorded. If you press **TIMER** to disengage the timer mode, these displays will appear even if all the programs are not recorded yet.

a– Press **OK** and step 2 will take place.
b– If you do not want to use Commercial Advance for the recorded program, press **STOP**.
c– If neither button is pressed within 60 seconds after the displays appear, step 2 will take place automatically.

NOTE:

Commercials can only be marked if Commercial Advance Record is enabled (☞ pg. 33).

IMPORTANT

If you press **STOP** in this step or stop marking midway in step 2 before the VCR is finished marking the commercials, data necessary for Commercial Advance will be lost and this feature will not work with the recording you made.

2 The VCR rewinds the tape automatically to the beginning of the recording and seeks out the commercial groups which have been detected.

During search and marking

* If you want to stop marking midway, press **STOP** so that "MARKING IN PROCESS" appears on the screen and "CA" blinks on the front display panel. While those are displayed (for 5 seconds), press **STOP** again to cancel Commercial Advance marking of the rest of the recordings.
* If you want to watch a TV program while the VCR is marking commercials, first press **TV/VCR** on the remote control, then use the TV's channel selector to select the channel you want to watch.



After having marked the start and end of all commercial groups of the recording(s), the VCR goes to its Stop mode. In the case of timer recording or Instant Timer Recording, the VCR shuts off automatically.

3 During playback, the VCR automatically (when enabled ☞ pg. 33) fast-motions (with blueback screen) (☞ pg. 38) during the commercial groups that were marked in step 2.
* When Commercial Advance is forwarding the tape to skip over commercials, "CA SKIP" will be displayed in the top right corner of the TV screen.



NOTES:

- *The Commercial Advance Record processes marks the tape when the picture fades to black and the audio fades to silence. Normally there is a period of black and no audio at the beginning and end of commercials.*
- *A black screen or a scene with no audio signal during a program may be detected as the start or end of a commercial.*
- *When using the timer to record two adjacent shows on the same channel, better commercial detection accuracy can be obtained by programming each show separately.*
- *If you record over a commercial start or end mark the Commercial Advance feature will not work correctly.*
- *Commercial Advance tested with 6 hours recordings, longer recordings may be possible depending on the number of commercials contained in the broadcast.*
- *The VCR will resume normal playback after skipping 15 minutes of tape if no commercial group end mark is detected.*
- *If the end of the tape is reached during recording, the display as illustrated in step 1 appears, then...*
  - *in the case of timer recording or Instant Timer Recording, after step 2 takes place, the cassette will be ejected and the power will shut off.*
  - *in the case of normal recording, after step 2 takes place, the VCR will rewind to the beginning of the tape.*
- *During automatic commercial skipping, if the user presses **STOP** or **PLAY**, the VCR will resume normal play; furthermore, if the tape is reversed to before the commercial group and played, the commercial group will not automatically be skipped.*
- *If an index code or the end of a recording is detected during Commercial Advance's forward fast-motion playback, normal playback resumes automatically.*
- *Commercial Advance disables commercial marking when the recording is less than 15 minutes.*
- *Commercial Advance does not mark the start of a commercial group when it is in the first or last two minutes of a recording.*
- *Commercial Advance does not mark commercial groups which are less than 59 seconds or groups which contain only one commercial.*
- *Some portions of programs may be detected as commercials.*
- *Some commercials may not be detected properly.*





"CA(Commercial Advance) RECORD" and "CA PLAYBACK" are set to " OFF " at the factory. To set Commercial Advance perform the following steps to set "CA RECORD" to "ON" and "CA PLAYBACK" to "AUTO".

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷**.

3 SELECT CA RECORD SET MODE

Move the highlight bar (arrow) to "CA RECORD" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷** to set to "ON".





4 SELECT CA PLAYBACK SET MODE

Move the highlight bar (arrow) to "CA PLAYBACK" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷** to set to "AUTO".



- Select "AUTO" to automatically skip over CA recorded commercials during playback.
- Select "MANUAL" to manually skip over CA recorded commercials by pressing **SKIP SEARCH**.
- Select "OFF" to disable CA Playback of CA recorded commercials.
- Press **SKIP SEARCH** during playback, with "MANUAL" (or "AUTO") selected, to fast-motion the tape to the end of the next commercial group or to the end of the recording, and then resume normal playback.

NOTE:

*If you press **SKIP SEARCH** during a commercial, the VCR may not resume normal playback at the end of the group of commercial. If this occurs press **PLAY** or **STOP** to resume normal playback.*

5 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTES:

- *If you set "CA RECORD" to "ON" while recording is in progress, the VCR will mark an index code at that location.*
- *You cannot change the "CA PLAYBACK" setting during Commercial Advance fast-motion playback.*
- *While recording is in progress with "CA RECORD" set to "ON", you cannot mark an index code manually, nor change the recording tape speed.*
- *During playback with "CA PLAYBACK" set to "OFF", pressing **SKIP SEARCH** starts fast-motion playback for 30 seconds on the counter (☞ pg. 26).*
- *If there is a power outage while recording is in progress with "CA RECORD" set to "ON", commercials that are recorded after the power is restored may not be detected properly.*
- *If you want to stop recording when "CA RECORD" is set to "ON", be sure to press **STOP**. If you press **POWER** or **TIMER** to stop recording, that may affect detection accuracy for commercials recorded afterwards.*

U.S. Pat. No. 5,333,091





Example



AV COMPU LINK Playback

Your VCR is compatible with JVC's AV COMPU LINK components, including amplifiers (or receivers) and televisions. AV COMPU LINK provides one touch control of the audio and video components that are linked via their AV COMPU LINK connectors.

For example: simply load a cassette in the VCR and press **PLAY** and the AV COMPU LINK components automatically power on, the TV's AV mode is selected and the VCR goes into play mode. (PLAY need not be pressed if the cassette's record safety tab is removed.)

1 MAKE CONNECTION

Connect your VCR to an AV COMPU LINK component as shown in the illustration in the left column.

- The mini-plug cable is a mono 3.5 mm mini-plug to mono 3.5 mm mini-plug connector.

2 ACCESS MAIN MENU SCREEN

Press **MENU**.

3 ACCESS FUNCTION SET SCREEN

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "FUNCTION SET", then press **OK** or **TIME SCAN** ▷.

4 ENABLE AV COMPU LINK PLAYBACK

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "AV COMPU-LINK", then press **OK** or **TIME SCAN** ▷ to set to "ON".

```
FUNCTION
→AUTO TIMER              OFF
 SUPERIMPOSE             ON
 AUTO SP→EP TIMER        OFF
 DIGITAL R3              ON
 VIDEO STABILIZER        OFF
 2ND AUDIO RECORD        OFF
 NEXT PAGE
 SELECT WITH (▲,▼) AND (OK)
 PRESS (MENU) TO END
```

```
 PREVIOUS PAGE
 AUDIO MONITOR           HI-FI
 S-VHS MODE              ON
→AV COMPU-LINK           ON
 VIDEO CALIBRATION       ON
 TIMESCAN AUDIO          ON
 FRONT AUX INPUT         VIDEO
 NEXT PAGE
 SELECT WITH (▲,▼) AND (OK)
 PRESS (MENU) TO END
```

5 RETURN TO NORMAL SCREEN

Press **MENU**.

6 PERFORM AV COMPU LINK PLAYBACK

Simply insert a cassette and press **PLAY** (if the cassette's record safety tab has been removed, playback begins automatically). Linked components are turned on, and the TV set to its AV mode, automatically!

NOTE:

Connection varies depending on the type of JVC TV you have. Please refer to the TV's instruction manual when making this connection.





Digital TBC/NR

Your VCR is equipped with the Digital TBC (Time Base Corrector) that removes jitter from fluctuating video signals to deliver a stable picture even with old tapes and rental cassettes. The on/off of Digital 3-DNR (Noise Reduction) which cuts noise and enables clear picture reproduction is also linked to this function.
* The default setting is "ON".

We recommend that you use the Digital TBC feature when...
... playing back a tape recorded on a camcorder.
... playing back a tape repeatedly used.
... using this VCR as the player for editing.

1 SELECT DIGITAL TBC/NR SET MODE

Press **DIGITAL TBC/NR** so that the button lights up.

- Pressing the button again turns off this function.

NOTES:

- *If you play back a tape recorded under poor TV reception condition, there may be cases where the picture becomes more stable with Digital TBC/NR set to off.*
- *When Digital TBC/NR is set to on, if you play back a tape where certain types of signals are recorded (using a PC or some character generators), the playback picture may be distorted. If this is the case, turn off Digital TBC/NR.*
- *Digital TBC/NR and Video Stabilizer (☞ pg. 28) cannot be used at the same time; if you turn on Digital TBC/NR when "VIDEO STABILIZER" is set to "ON", Video Stabilizer will be automatically turned "OFF". Make sure Digital TBC/NR is off when you want to use Video Stabilizer.*

Digital R³

Digital R³ picture system applies edge correction to the luminance signal to enhance detail.

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

```
MAIN MENU

→ FUNCTION SET
  TUNER SET
  INITIAL SET
  HI-FI REC LEVEL CTL

PRESS (▲,▼), THEN (OK)
PRESS (MENU) TO END
```

3 SELECT DIGITAL R3 SET MODE

Move the highlight bar (arrow) to "DIGITAL R3" by pressing **CH ▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷ to set to "ON".

```
FUNCTION
AUTO TIMER              OFF
SUPERIMPOSE              ON
AUTO SP→EP TIMER        OFF
→ DIGITAL R3             ON
VIDEO STABILIZER        OFF
2ND AUDIO RECORD        OFF
NEXT PAGE
SELECT WITH (▲,▼) AND (OK)
PRESS (MENU) TO END
```

4 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTES:

- *Normally it is recommendable to keep "DIGITAL R3" set to "ON".*
- *Depending on the type of tape being used, picture quality may be better with "DIGITAL R3" set to "OFF".*
- *If you use this VCR as the player for editing, be sure to set "DIGITAL R3" to "OFF" before starting.*

Active Video Calibration

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





Active Video Calibration checks the condition of the tape during recording and playback, and compensates for poor reproduction to provide the best quality recording and playback pictures. *The default setting is "ON".

Preparation

1 TURN ON THE VCR

Press **POWER**.

2 ACCESS MAIN MENU SCREEN

Press **MENU**.

3 ACCESS FUNCTION SET SCREEN

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "FUNCTION SET", then press **OK** or **TIME SCAN** ▷.

```
MAIN MENU
→ FUNCTION SET
  TUNER SET
  INITIAL SET
  HI-FI REC LEVEL CTL

PRESS (▲,▼), THEN (OK)
PRESS (MENU) TO END
```

4 SELECT VIDEO CALIBRATION MODE

Press **CH ▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "VIDEO CALIBRATION", then press **OK** or **TIME SCAN** ▷ to set to "ON" or "OFF".

NOTE:

When recording or when playing back tapes recorded on this VCR set the Video Calibration to "ON".

```
FUNCTION
→ AUTO TIMER              OFF
  SUPERIMPOSE             ON
  AUTO SP→EP TIMER        OFF
  DIGITAL R3              ON
  VIDEO STABILIZER        OFF
  2ND AUDIO RECORD        OFF
  NEXT PAGE
SELECT WITH (▲,▼) AND (OK)
PRESS (MENU) TO END
```

```
  PREVIOUS PAGE
  AUDIO MONITOR           HI-FI
  S-VHS MODE              ON
  AV COMPU-LINK           ON
→ VIDEO CALIBRATION       ON
  TIMESCAN AUDIO          ON
  FRONT AUX INPUT         VIDEO
  NEXT PAGE
SELECT WITH (▲,▼) AND (OK)
PRESS (MENU) TO END
```

5 RETURN TO NORMAL SCREEN

Press **MENU**.





Playback

The VCR assesses the quality of the tape once you start playback.

Perform steps **1** and **2** on page 22 ("Simple Playback") before continuing.

1 START PLAYBACK

Press **PLAY**.

- The VCR adjusts the playback picture quality based on the quality of the tape in use.

—VIDEO CALIBRATION —

NOTES:

- *When using rental tapes, or tapes recorded on other VCRs, set "VIDEO CALIBRATION" in step **4** of the Preparation procedure to either "ON" or "OFF" as desired to give the best picture (☞ pg. 36).*
- *The Video Calibration screen only appears at the beginning of automatic tracking. Even though the screen doesn't appear after that, the Video calibration function is operative.*
- *To display the Video Calibration screen, "SUPERIMPOSE" must be set to "ON" or the Video Calibration screen will not appear (☞ pg. 29).*

Recording

Perform steps **1** – **3** on page 23 ("Simple Recording") before continuing.

1 START RECORDING

Press and hold **REC** and press **PLAY** on the remote control, or press **REC** on the VCR's front panel.

- The VCR takes about 7 seconds to assess the quality of the tape in use, then recording begins with the picture level optimized.

DURING CALIBRATION

START END
ACTIVE VIDEO CALIBRATION

CALIBRATION COMPLETE

START END
ACTIVE VIDEO CALIBRATION

NOTES:

- *Calibration occurs immediately prior to both the first SP and the first EP recording after inserting the cassette. It does not take place during recording.*
- *In the case of timer recording, calibration takes place for both SP and EP before the first timer recording after inserting the cassette (regardless of the tape speed selected for that recording).*
- *Once the cassette is ejected, the calibration data is canceled. The next time the cassette is used for recording, calibration is re-performed.*
- *While Video Calibration is operative, the **PAUSE** button will not function.*
- *To display the Video Calibration screen, "SUPERIMPOSE" must be set to "ON" or the Video Calibration screen will not appear (☞ pg. 29).*

ATTENTION

- As calibration takes place before recording actually starts, there is a delay of about 7 seconds after **REC** and **PLAY** on the remote, or **REC** on the VCR's front panel, are pressed. To make sure you record the desired scene or program completely, first perform the following steps:
  1) Press and hold **PAUSE**, and press **REC** to engage the RECORD PAUSE mode.
     - The VCR then automatically checks the condition of the tape and, after about 7 seconds, re-enters RECORD PAUSE.
  2) Press **PLAY** to start recording.
- If you want to bypass Video Calibration and start recording right away, set "VIDEO CALIBRATION" to "OFF" in step **4** of the Preparation procedure (☞ pg. 36).

TimeScan





Your VCR is equipped with the TimeScan function. TimeScan allows noise free pictures to be displayed on your TV screen in the forward and reverse search modes. Audio will be played back at normal speed during any of the TimeScan modes (☞ pg. 39). TimeScan allows you to view a program in search mode while listening to the audio.

NOTES:

- *"TIMESCAN AUDIO" must be set to "ON", or the sound will not be heard in TimeScan mode (☞ pg. 39).*
- *The audio will not synchronize with the video in TimeScan modes.*
- *During 1.5x speed TimeScan the audio playback speed will also be 1.5 times normal, so dialog will sound fast-talking.*
- *In Pause mode 3 seconds (approx.) of audio will be played back repeatedly. (☞ pg. 24)*
- *In TimeScan search modes some of the audio information will not be played so that the audio can keep up with the video.*

Audio signal during TimeScan

Playback tape



Sound of ①, ③ and ⑤ is heard.
Sound of ② and ④ is not heard.
Output audio signal is normal (monaural) sound.

Variable-Speed Search/ Reverse Motion Playback

1 ACTIVATE VARIABLE-SPEED SEARCH

During playback or still, repeatedly press and release **TIME SCAN** ⏮ or ⏭ to select the search speed. (Refer to the chart on page 39 for playback speeds).

- To increase the speed in the forward direction, press and release ⏭ repeatedly to select the various forward search modes.
- To decrease the speed in the forward direction, press and release ⏮.
- To play in reverse slow motion, and in reverse play mode, continue to press ⏮ repeatedly after selecting all the forward slow motion modes. (Refer to the chart on page 39 for playback speeds).

To resume normal playback, press **PLAY**.

If the superimposed indication jitters vertically during TimeScan, adjust until the optimum condition is achieved by using manual tracking (☞ pg. 26).

TimeScan

Names of special-effects playback	Reverse						Forward						
	Search			Play	Slow-Motion (Pro-Slow)**		Still*	Slow-Motion (Pro-Slow)**		Play	Search				
Speed	-7x	-5x	-3x	-1x	-1/2x	-1/3x	0	1/3x	1/2x	1x	1.5x	2x	3x	5x	7x
Audio output	Audio is output.				Audio is not output.		Audio is output.	Audio is output.		Audio is output.					

* Still mode cannot be engaged using the **TIME SCAN** buttons. Still mode can only be engaged by pressing the **PAUSE** button.

** Smooth slow motion delivering an uninterrupted moving image without distortion.

- The speed is shown in the upper right corner of the TV screen for approx. 5 seconds.
- The TimeScan search speed is the same for SP and EP recordings.
- To resume normal playback, press **PLAY**.
- Picture may be distorted at the position where the recording speed is switched.
- The picture may be noisy for a moment when you change the playback speed.
- During high-speed search with a tape containing both SP and EP recordings, the search speed will change automatically to 7x normal playback speed with TimeScan when the recording tape speed switches from EP to SP.
- Depending on the tape in use, noise may appear or the upper part of the picture may be distorted.
- Picture may appear distorted in comparison to normal playback.
- In TimeScan mode there will be a time lag between the video and the audio and noise may appear in the audio signal.
- TimeScan sound quality will differ in comparison to normal playback.
- When material such as music videos where there is non-stop sound (very few breaks in the soundtrack) are viewed at 2x normal speed, the audio playback may be faster than normal.
- When the playback direction is reversed, it takes approximately 6 seconds until sound is heard.
- ±1/3x slow-motion playback is possible with SP recordings only.
- Depending on the type of tape contents, the sound may not be clear during forward slow-motion playback.
- Pro-Slow cannot be activated by pressing **PAUSE** for longer than 2 seconds.
- Depending on the type of tape in use, noise may appear during Pro-Slow. When this happens, try manual tracking (☞ pg. 26).
- The operations by the **JOG** dial/**SHUTTLE** ring do not include TimeScan; noise will appear on the screen and audio will not be output.

If you don't want to hear TimeScan audio, set "TIMESCAN AUDIO" to "OFF".

TimeScan Audio

The audio output can be set ON/OFF during TimeScan. Select ON/OFF as required. *The default setting is "ON".

1. Press **MENU** to access the Main Menu screen.
2. Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH▲▼** or **TIME SCAN△▽**, then press **OK** or **TIME SCAN ▷**.
3. Move the highlight bar (arrow) to "TIMESCAN AUDIO" by pressing **CH▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN▷** to select to "ON" or "OFF".
4. Press **MENU** to return to the normal screen.



Recording Features



Record One Program While Watching Another

1 ENGAGE TV MODE

During recording...

- Press **TV/VCR**. The VCR's VCR indicator goes out. (If you are using the RF connection (☞ pg. 6) to view the output from your VCR, the TV broadcast being recorded disappears.)
- If you are using the AV connection (☞ pg. 6) to view the output from your VCR, change the TV's input mode from AV to TV.

2 SELECT CHANNEL FOR VIEWING

Use the TV's channel selector to set the channel you want to watch.

Display Elapsed Recording Time

1 RESET COUNTER TO ZERO

Before recording starts, press **C.RESET.** The counter resets to zero and displays the exact elapsed time as the tape runs.

2 DISPLAY ELAPSED TIME ON SCREEN

During recording, press **ENTER** at any time to see the elapsed time.
All indications corresponding to the current status of the VCR are displayed for 5 seconds. The counter display remains on the screen indicating the elapsed time.
Press **ENTER** again to remove the display.

- Make sure "SUPERIMPOSE" is set to "ON" (☞ pg. 29).
- The indications are not recorded.
- Press **DISPLAY** to change to the COUNT display if "REMAIN" is displayed.

Display Tape Remaining Time

1 DISPLAY COUNTER INFORMATION

Press **ENTER**.
All indications corresponding to the VCR's current status are displayed for 5 seconds. The counter display remains on the screen indicating the elapsed time.

2 DISPLAY TAPE REMAINING TIME

Press **DISPLAY** until "REMAIN" appears on screen. The approximate tape remaining time appears on the TV screen and also on the VCR display panel with a "◣" indicator.

- The tape remaining time is calculated based on the tape speed (SP or EP) being used. The indicated remaining time is only an estimate.
- Press **DISPLAY** to change the on-screen display from REMAIN to COUNT and vice versa; and to show counter reading, channel number, clock time or tape remaining time on the front display panel. Then channel number will not be displayed when the VCR is playing a tape.

3 EXIT THE DISPLAY

Press **ENTER** again.

NOTES:

- *"SUPERIMPOSE" must be set to "ON", or the on-screen display will not appear (☞ pg. 29).*
- *Near the beginning of the tape, the tape remaining estimate may be inaccurate. However, the estimate becomes more accurate as the tape comes closer to the end.*
- *Depending on the type of tape used, the tape remaining time reading may not appear right away, or may not be correct. "- -:- -" may sometimes appear, or the display may blink on occasion.*
- *The tape remaining time indication is not accurate when using VHS-C tapes with VHS-C adapter.*





S-VHS (Super VHS), S-VHS ET and VHS

Your VCR can record in S-VHS, S-VHS ET or VHS.

S-VHS allows you to make high quality video recordings with a horizontal resolution of 400 lines. This compares with the 240 lines of resolution of normal VHS recordings. To achieve the highest quality picture we recommend that you record in S-VHS mode.

By using S-VHS ET it is possible to record and play back with S-VHS picture quality on VHS cassettes with this VCR. For details, refer to page 42.

To record in S-VHS;
- perform the steps **1 – 4** below to set the "S-VHS MODE" to "ON".
- then, insert a cassette marked "S-VHS", the S-VHS indicator will light on the display panel.

The S-VHS recording mode will be automatically selected.

To record in S-VHS ET on a VHS high grade cassette;
- press **S-VHS ET** and set to "ON".

☞ "Super VHS ET" on page 42.

To record in VHS;
- insert a cassette marked "VHS".
- press **S-VHS ET** and set to "OFF".

The VHS recording mode will be automatically selected regardless of the S-VHS mode setting.

To record in VHS on an S-VHS cassette;
- insert the cassette marked "S-VHS", the S-VHS indicator will light on the display panel.
- then, perform the steps **1 – 4** below to set the "S-VHS MODE" to "OFF"; the S-VHS indicator will go out.

The VHS recording mode will be selected.

NOTE:

Tapes recorded in S-VHS or S-VHS ET mode can not be played back successfully on normal VHS VCRs.

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH▲▼** or **TIME SCAN△▽**, then press **OK** or **TIME SCAN ▷**.

3 SELECT S-VHS MODE

Move the highlight bar (arrow) to "S-VHS MODE" by pressing **CH▲▼** or **TIME SCAN△▽**, then press **OK** or **TIME SCAN ▷** to set to "ON" or "OFF".



4 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTE:

When playing back a tape that has been recorded in S-VHS or S-VHS ET, the S-VHS indicator lights on the display panel regardless of the "S-VHS MODE" setting.



Super VHS ET

Your VCR is equipped with Super VHS ET that makes it possible to record with S-VHS picture quality on VHS cassettes.

1 SELECT S-VHS ET SET MODE

Press **S-VHS ET**. The current setting appears on the screen for about 5 seconds.



2 ENGAGE S-VHS ET MODE

While the current setting is displayed on the screen, press **S-VHS ET** again to set to "ON".

- The "S-VHS" indicator lights on the front display panel.

NOTES:

- *You cannot activate the S-VHS ET function...*
  ...while recording is in progress.
  ...while timer-recording (incl. Instant Timer Recording ☞ pg. 45) is in progress.
  ...while Video Calibration (☞ pg. 36) is in progress.
  ...when the VCR's power is off.
- *S-VHS ET does not work with S-VHS tapes.*

S-VHS ET

This facility allows recording with S-VHS picture quality on VHS cassettes. You can play back those cassettes recorded in S-VHS ET on a VCR equipped with S-VHS ET.

NOTES:

- *To obtain the highest quality recording and playback pictures over a longer period on this model, S-VHS recording on S-VHS tape is recommended.*
- *You can play back S-VHS ET recordings not only on this VCR but also on another VHS VCR equipped with S-VHS ET.*
  ** It is recommended to specifically label S-VHS ET recordings so you can easily distinguish them from regular VHS recordings.*
- *S-VHS ET recordings can also be played back on an S-VHS VCR or a VHS VCR equipped with SQPB (S-VHS QUASI PLAY-BACK) function. However, there may be cases where S-VHS ET playback is not possible on a particular VCR.*
- *Frequent still, frame-by-frame and slow-motion playback may damage the tape and cause picture degradation.*
- *With some tapes, better picture quality may not be obtained even with S-VHS ET recording. It is recommended that you do test record beforehand to make sure whether better results can be obtained.*
- *High Grade tapes are recommended for superior results.*
- *Make sure that "VIDEO CALIBRATION" is set to "ON" at the Function screen (☞ pg. 36).*
- *During S-VHS ET playback, noise may appear depending on tape quality.*
- *Noise may appear during still, frame-by-frame, slow-motion playback and TimeScan search.*
- *If the playback picture becomes blurred or interrupted, use a cleaning cassette.*





Stereo And SAP (Second Audio Program)

Your VCR's built-in MTS decoder enables reception of Multi-channel TV Sound broadcasts.
When the channel is changed on the VCR ...

- The "STEREO" indication appears on the screen for about 5 seconds if the program is a stereo broadcast.
- The "SAP" indication appears on the screen for about 5 seconds if the program is a SAP broadcast.
- Both indications appear when a stereo program is accompanied by SAP audio.

To Record Stereo Programs . . .
. . . simply follow the basic recording procedure.

To Listen To Stereo Soundtrack During Recording . . .
. . . set "AUDIO MONITOR" to "HI-FI" at the Function screen (☞ pg. 30).

To Record SAP Programs . . .

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH▲▼** or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

3 SELECT 2ND AUDIO RECORD SET MODE

Move the highlight bar (arrow) to "2ND AUDIO RECORD" by pressing **CH▲▼** or **TIME SCAN**△▽, then press **OK** or **TIME SCAN** ▷ to set to "ON".

FUNCTION	
AUTO TIMER	OFF
SUPERIMPOSE	ON
AUTO SP→EP TIMER	OFF
DIGITAL R3	ON
VIDEO STABILIZER	OFF
→2ND AUDIO RECORD	ON
NEXT PAGE	
SELECT WITH (▲,▼) AND (OK)	
PRESS (MENU) TO END	

4 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTES:

- *If a SAP program is received and "2ND AUDIO RECORD" is set to "ON", the SAP audio is recorded on both the Normal and Hi-Fi tracks. The main audio program is not recorded.*
- *If a non-SAP program is received, the main audio is recorded on both the Hi-Fi and Normal audio tracks.*





Hi-Fi Audio Recording Level Control

Your VCR allows manual adjustment of the Hi-Fi audio recording level. Although the preset audio recording level is satisfactory for normal recording, if the sound you are going to record is too loud or too low, adjust the audio recording level while referring to the VCR's audio level meters.

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS HI-FI REC LEVEL CONTROL SCREEN

Move the highlight bar (arrow) to "HI-FI REC LEVEL CTL" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷**.

3 SELECT MODE

Move the highlight bar (arrow) to "MANUAL" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷**.



4 ADJUST AUDIO RECORDING LEVEL

Press **TIME SCAN △** or **▽**.

- To move the on-screen's audio levels by one division of the scale, press **TIME SCAN △** or **TIME SCAN ▽** briefly for 5 times in succession. To move the audio levels faster, keep **TIME SCAN △** or **TIME SCAN ▽** presssed.
- Adjust the recording level while watching the VCR's audio level meters. Set the level so that maximum volume causes the meters to vary between 0dB to 4dB.

5 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTE:

- *Noise will increase if the recording level is too low, while distortion will increase if the level is too high.*

Instant Timer Recording (ITR)





This easy method lets you record from 30 minutes to 6 hours (selectable in 30-min. increments) and shuts the VCR off after recording is finished.

1 START RECORDING

Press **REC** on the front panel.

2 ENGAGE ITR MODE

Press **REC** again. " ◌ " blinks and 0:30 appears on the front display panel.

3 SET RECORDING DURATION

If you want to record for more than 30 minutes, press **REC** to extend the time. Each press extends recording time by 30 minutes.

NOTES:

- *You can only perform ITR using the **REC** button on the VCR's front panel.*
- *After you set the ITR time, the previous display reappears.*
- *To check the remaining time, press **REC** once during recording and the remaining time will be displayed for about 5 seconds. Be careful not to press **REC** again within these 5 seconds, or you will round the recording time up to the next 30 minute increment.*

VCR Plus+ Timer Programming

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





Timer recording allows you to program the VCR to automatically record a program that will be broadcast at some future time.
The timer record function can be programmed using VCR Plus+ or Express Timer Programming up to 8 shows as far as a year in advance. (☞ pg. 46 or 50)
The VCR Plus+ timer programming system eliminates the need to input channel, date, start and stop time data when setting the timer record function. Simply key in the PlusCode number for the TV program you wish to record and the VCR's timer will be automatically programmed. (The PlusCodes are the numbers next to the programs in most TV listings.)

1 LOAD A CASSETTE

Make sure the record safety tab is present.

- The VCR's power comes on automatically.

2 ACCESS VCR PLUS+ SCREEN

Press **PROG.** on the remote control.



- The clock must be set in order to access the VCR Plus+ screen. If you haven't set the clock, the Main Menu screen appears after an error message is displayed.
  Refer to page 8 for the Plug & Play procedure or page 11 for the clock setting procedure.

3 ENTER PLUSCODE NUMBER

Press the appropriate **NUMBER** keys to enter the PlusCode number printed in the TV listings for the TV program you wish to record and press **OK**.
*If the Guide Channel Set screen appears, go to step **4**.*
*If the VCR Plus+ Program screen appears, go to step **5**.*



- To make corrections, press **CANCEL** and input the correct PlusCode number.

4 INPUT RECEIVING CHANNEL NUMBER

The Guide Channel Number, which is assigned to the TV or cable station for the PlusCode number that you entered in step **3**, will appear automatically on the Guide Channel Set screen. Input the number of the channel on which the broadcast for the PlusCode number is received on the VCR or cable box using the **NUMBER** keys, **CH ▲▼** or **TIME SCAN** △▽, then press **OK**.



- The Guide Channel Set screen appears only when you input the PlusCode number of a station for which the Guide Channel number has not previously been set.
- If you receive your channels with a cable box and if you have properly set your Controller, "CABLE CH" appears in place of "VCR CH". If not, refer to pages 16 – 18.



5 CHECK PROGRAM DATA

The PlusCode number you entered and the matching Timer-Recording information is displayed on the Program screen. Check to make sure it's accurate.

```
PROGRAM 1
(VCR PLUS+ 12345678)
START          STOP
8:00PM    →    10:00PM
DATE           CH
12/24/98       12  SP
THU
PRESS (8=DAILY, 9=WEEKLY
STOP+/– = STOP TIME, SP/EP)
PRESS (OK) TO END
```

- To change the stop time, press **STOP +/–**.
- To timer-record daily or weekly serials, press **DAILY** (**NUMBER** "8") or **WEEKLY** (**NUMBER** "9"). "DAILY" or "WEEKLY" appears on the Program screen. Pressing the button again makes each corresponding display disappear.
- If you made a mistake, press **CANCEL** to access the VCR Plus+ screen again and input the correct PlusCode number.
- If the PlusCode number you inputted is incorrect, "ERROR" may appear on the screen to advise you of the error. This happens when the PlusCode number is for a program which has already passed. "ERROR" is displayed for about 5 seconds and the VCR Plus+ screen reappears.

6 SET TAPE SPEED

Press **SP/EP**.

7 RETURN TO NORMAL SCREEN

Press **PROG.** or **OK**. "PROGRAM COMPLETED" appears on the screen for about 5 seconds, then normal screen appears.

8 ENGAGE TIMER MODE

Press **TIMER**. The VCR turns off automatically and "⏲" is displayed on the display panel.

ATTENTION

If there is a conflict in the timer schedule and one program overlaps with another, only the parts shown below in gray will be recorded.

Pattern 1: *The program with the lower program number will be recorded.*



Pattern 2: *The program that is broadcast earlier will be recorded.*



Pattern 3: *The program that is broadcast earlier will be recorded, followed by the remaining portion of the other program.*



IMPORTANT

If you have moved to a different area or if a broadcasting station's channel number has been changed, the wrong VCR or CABLE CH number will be displayed on the VCR Plus+ Program screen in step **5**. When this happens, set the correct the Guide Channel number for that station. (☞ pg. 48, "VCR Plus+ Setup")

NOTES:

- *To disengage the timer before recording starts, press **TIMER** again. Pressing once more re-engages it.*
- *In case of a power failure after programming, the VCR's memory backup keeps your selections for approximately 10 minutes.*
- *When timer-recording cable channels received through a Cable Box, be sure to keep the Cable Box set to ON.*

VCR Plus+ Setup

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





IMPORTANT

If you have moved to a different area or if a broadcasting station's channel number has been changed, the wrong VCR or CABLE CH number will be displayed on the VCR Plus+ Program screen (☞ step **5** on page 47). When this happens, perform the following steps to set the correct the Guide Channel number for that station.

To ensure that VCR Plus+Timer Recording operates correctly it is necessary to set the VCR Plus+ "Guide Channel Set " for each station. Please read the following information carefully.

VCR Plus+ Guide Channel Matching

VCR Plus+ assigns a VCR Plus+ "Guide Channel" to broadcast and cable TV channels. These Guide Channel numbers are also called the VCR Plus+ Channel Codes. Most TV listings have a section, usually a chart, indicating the "Guide Channel" numbers assigned to each station. For accurate VCR Plus+ Programming the VCR Plus+ Guide Channel number for each station should match the channel number on which it is received in your area.

NOTES:

- *In many instances the VCR Plus+ Guide Channel numbers for cable and broadcast TV stations **DO NOT** match the channel number on which it is received by your VCR or cable box. Check your TV listing, or contact your cable supplier for details.*
- *Many broadcast TV stations can be viewed on cable. Check your TV listing, or contact your cable supplier for details.*

1 TURN ON THE VCR

Press **POWER**.

2 ACCESS MAIN MENU SCREEN

Press **MENU**.

3 ACCESS INITIAL SET SCREEN

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "INITIAL SET", then press **OK** or **TIME SCAN** ▷.







4 ACCESS GUIDE CHANNEL SET SCREEN

Press **CH▲▼** or **TIME SCAN** △▽ to move the highlight bar (arrow) to "GUIDE CHANNEL SET", then press **OK** or **TIME SCAN** ▷.



5 INPUT GUIDE CHANNEL NUMBER

Press **CH▲▼**, **TIME SCAN** △▽ or the appropriate **NUMBER** keys to input the VCR Plus+ Guide Channel number as shown in the TV listing. Then press **OK** or **TIME SCAN** ▷.

(Ex.) When inputting the Guide Channel number 6 for WNJU(Ind.)



- If you receive your channels with a cable box and if you have properly set your Controller, "CABLE CH" appears in place of "VCR CH". If not, refer to pages 16 – 18 and re-perform the procedure.

6 INPUT RECEIVING CHANNEL NUMBER

Press **CH▲▼**, **TIME SCAN** △▽ or the appropriate **NUMBER** keys to input the number of the channel on which the Guide Channel's broadcasts are received. Then press **OK** or **TIME SCAN** ▷.

(Ex.) If WNJU(Ind.) is received on channel 47



- Repeat steps **5** and **6** for each instance.

7 RETURN TO NORMAL SCREEN

Press **MENU**.

Express Timer Programming

Turn on the TV and select the VCR channel 3 or 4 (or AV mode).





You can directly program the VCR's timer to record up to 8 shows, as far as a year in advance. Remember, the clock must be set before you can program the timer (☞ pg. 8 or 11).

1 LOAD A CASSETTE

Make sure the record safety tab is intact. If not, cover the hole with adhesive tape, then load it into the VCR.

- The VCR comes on, and the counter is reset, automatically.

2 ACCESS VCR PLUS+ SCREEN

Press **PROG.**

3 ACCESS PROGRAM SCREEN

Press **START +/–**. (If you're just starting out, "PROGRAM 1" appears.)



4 SET PROGRAM START TIME

Press **START +/–** to enter the time you want recording to start.

- Press and hold **START +/–** to move in 30-minute increments, or press and release repeatedly to move 1 minute at a time.



5 SET PROGRAM STOP TIME

Press **STOP +/–** to enter the time you want recording to stop.

- Press and hold **STOP +/–** to move in 30-minute increments, or press and release repeatedly to move 1 minute at a time.

6 SET PROGRAM DATE

Press **DATE +/–**. (The current date is displayed on screen. The date you enter appears in its place.)

7 SET CHANNEL NUMBER

Press **CH +/–**.

- If you are using a DBS receiver, see "ATTENTION FOR DBS RECEIVER USERS" on next page.
- Holding down **CH +/–** rapidly scans through the channels.



8 SET TAPE SPEED

Press **SP/EP** to set the tape speed.

9 RETURN TO NORMAL SCREEN

Press **PROG.** or **OK**. "PROGRAM COMPLETED" appears on the screen for about 5 seconds, then normal screen appears.

10 ENGAGE TIMER MODE

Press **TIMER**. The VCR turns off automatically and "◴" is displayed on the display panel.

To Timer-Record Weekly Or Daily Serials . . .
. . . anytime during steps **3** through **9**, press **WEEKLY** (**NUMBER** key "9") for weekly serials or **DAILY** (**NUMBER** key "8") for daily serials (Monday–Friday). Either "WEEKLY" or "DAILY" appears on the screen. Pressing the button again makes the corresponding indication disappear.

NOTES:

- *To disengage the timer before recording starts, press **TIMER** again. Pressing once more re-engages it.*
- *In case of a power failure after programming, the VCR's memory backup keeps your selections for approximately 10 minutes.*
- *Programs that start after midnight must have the next day's date.*
- *After timer recording is completed, the VCR's power goes off automatically.*
- *You can program the timer while a regular recording is in progress; the on-screen menu will not be recorded.*
- *If the end of tape is reached during timer recording, the cassette is automatically ejected.*
- *When timer-recording cable or satellite channels through an external tuner, be sure to keep the cable box or satellite receiver's power ON.*

ATTENTION FOR DBS RECEIVER USERS

If you are using a DBS receiver (unless "DBS RECEIVER SET" is set to "OFF" ☞ pg. 20), the BAND indication (TV or CATV or DBS) appears under the channel number display. If the channel number that has been entered requires that the band be set, "7=DBS" is displayed on the screen. Press the **NUMBER** key "7" to select the desired band.

PROGRAM 1
START 8:00AM → STOP 9:00PM
DATE 12/24/98 CH 110 SP
THU DBS
PRESS (+/–, SP/EP, 8=DAILY, 9=WEEKLY, 7=DBS), THEN (OK)
PRESS (PROG.) TO END

a– TV : To timer-record a regular TV program received on the VCR.
b– CATV : To timer-record a cable TV program received on the VCR, or through a cable box (unless "CABLE BOX SET" is set to "OFF" ☞ pg.17).
c– DBS : To timer-record a satellite program received through a DBS receiver.

- If "BAND" is set to "TV" at the Tuner Set screen (☞ pg.14) and "CABLE BOX SET" is set to "OFF" at the Cable Box Set screen (☞pg. 17), CATV will not be displayed on the Program screen; If "BAND" is set to "CATV" or "CABLE BOX SET" is set to "ON", TV will not be displayed.

ATTENTION

If there is a conflict in the timer schedule and one program overlaps with another, only the parts shown below in gray will be recorded.

Pattern 1: *The program with the lower program number will be recorded.*



Pattern 2: *The program that is broadcast earlier will be recorded.*



Pattern 3: *The program that is broadcast earlier will be recorded, followed by the remaining portion of the other program.*







Check, Cancel And Revise Programs

1 DISENGAGE TIMER

Press **TIMER**, then press **POWER**.

2 ACCESS PROGRAM CHECK SCREEN

Press **PROG. CHECK**.

PR	START	STOP	CH	DATE
1	8:00P	10:00	12	12/24
2	10:00A	10:45	40	12/25
3	11:30P	01:00	125	12/25
4				
5				
6				
7				
8				

PRESS (CHECK) TO NEXT

3 ACCESS PROGRAM SCREEN

Press **PROG. CHECK** again to check more information. Each time you press **PROG. CHECK**, the next program's information appears.

To Cancel Or Revise A Program...

4 CANCEL OR REVISE A PROGRAM

To cancel a program, press **CANCEL** at the appropriate program screen.
To revise a program, press the appropriate button: **START+/–**, **STOP+/–**, **DATE+/–**, **CH+/–**, **SP/EP**.

5 RETURN TO NORMAL SCREEN

Press **PROG. CHECK** as many times as necessary. If there are still programs remaining, go to step **6**.

6 RE-ENGAGE TIMER

Press **TIMER**.

Auto SP→EP Timer

If, when recording in SP mode, there is not enough tape to record the entire program, the VCR automatically switches to EP mode to allow complete recording. This feature is especially handy when recording a program of more than 2 hours in length.

For Example . . .

Recording a program of 140 minutes in length onto a 120-minute tape

Approximately 110 minutes	Approximately 30 minutes
SP mode	EP mode

Total 140 minutes

Make sure you set "AUTO SP→EP TIMER" to "ON" at the Function screen before the timer recording starts.

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH** ▲▼ or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

3 SELECT AUTO SP→EP TIMER SET MODE

Move the highlight bar (arrow) to "AUTO SP→EP TIMER" by pressing **CH** ▲▼ or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷ to set to "ON".



4 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTES:

- *If you have programmed the VCR to timer-record 2 or more programs, the second program and those thereafter may not fit on the tape if you set the Auto SP→EP Timer mode to "ON". In this case, make sure the mode is not engaged, then set the tape speed manually during timer programming.*
- *In order to ensure that the recording fits on the tape, this feature may leave a slight non-recorded section at the end of the tape.*
- *There may be some noise at the point on the tape where the VCR switches from SP to EP mode.*
- *The Auto SP→EP Timer feature is not available during ITR (Instant Timer Recording), and the feature will work with the following tapes: T(ST)-30, T(ST)-60, T(ST)-90, and T(ST)-120.*

Auto Timer

When the Auto Timer is set to ON the timer is automatically engaged when the VCR's power is turned off. It is automatically disengaged when the VCR is powered back on.

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS FUNCTION SET SCREEN

Move the highlight bar (arrow) to "FUNCTION SET" by pressing **CH**▲▼ or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

3 SELECT AUTO TIMER SET MODE

Move the highlight bar (arrow) to "AUTO TIMER" by pressing **CH**▲▼ or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷ to set to "ON" or "OFF".



4 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTE:

*For safety, when AUTO TIMER is set to "OFF", all other VCR functions are disabled while the Timer mode is engaged. To disengage the timer, press **TIMER**.*

Edit From A Camcorder







You can use a camcorder as the player and your VCR as the recorder.

1 MAKE CONNECTIONS

Connect an AV cable between the camcorder's VIDEO OUT and AUDIO OUT connectors and your VCR's VIDEO IN and AUDIO IN connectors.

- If connecting a camcorder with an S-VIDEO output connector, it is recommended to use the S-VIDEO connection to minimize picture degradation while editing.
- When a Master Edit Control-equipped JVC camcorder is used, the camcorder is capable of controlling your VCR. The mini-plug cable is a mono 3.5 mm mini-plug to mono 3.5 mm mini-plug connector.
- If connecting to a camcorder with a monaural output, connect the audio output connector on the camcorder to AUDIO IN L of the VCR.

2 LOAD A CASSETTE

Insert the cassette to be recorded on into the recorder.

3 SET RECORDER'S INPUT MODE

Set to "AUX". Press the **NUMBER** key "0" and/or **CH** to select depending on the connector being used – "L-1" for the rear panel input connectors, or "F-1" for the front panel input connectors.

4 ACCESS MAIN MENU SCREEN

Press **MENU**.

5 ACCESS FUNCTION SET SCREEN

Press **CH ▲▼** or **TIME SCAN △▽** to move the highlight bar (arrow) to "FUNCTION SET", then press **OK** or **TIME SCAN ▷**.

6 SELECT AUX INPUT SET MODE

a– FRONT S-VIDEO IN : Move the highlight bar (arrow) to "FRONT AUX INPUT" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷** to set to "S-VIDEO".

b– FRONT VIDEO IN: Move the highlight bar (arrow) to "FRONT AUX INPUT" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷** to set to "VIDEO".

c– REAR S-VIDEO IN: Move the highlight bar (arrow) to "REAR AUX INPUT" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷** to set to "S-VIDEO".

d– REAR VIDEO IN: Move the highlight bar (arrow) to "REAR AUX INPUT" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷** to set to "VIDEO".







7 RETURN TO NORMAL SCREEN

Press **MENU**.

*If you are using a JVC Master Edit Control-equipped camcorder — go to step **8***

*If you are not using a JVC Master Edit Control-equipped camcorder — go to step **12***

8 ACCESS MAIN MENU SCREEN

Press **MENU**.

9 ACCESS FUNCTION SET SCREEN

Press **CH ▲▼** or **TIME SCAN △▽** to move the highlight bar (arrow) to "FUNCTION SET", then press **OK** or **TIME SCAN ▷**.

10 ENABLE REMOTE PAUSE FUNCTION

Press **CH ▲▼** or **TIME SCAN △▽** to move the highlight bar (arrow) to "AV COMPU-LINK", then press **OK** or **TIME SCAN ▷** to set to "OFF".

- The REMOTE PAUSE/AV COMPU-LINK connector works as the AV Compulink Playback connector when "AV COMPU-LINK" is set to "ON" (☞ pg. 31), and works as the Remote Pause connector when "AV COMPU-LINK" is set to "OFF".



11 RETURN TO NORMAL SCREEN

Press **MENU**.

12 ACCESS MAIN MENU SCREEN

Press **MENU**.

13 ACCESS FUNCTION SET SCREEN

Press **CH ▲▼** or **TIME SCAN △▽** to move the highlight bar (arrow) to "FUNCTION SET", then press **OK** or **TIME SCAN ▷**.

14 SELECT TAPE DUB MODE

Move the highlight bar (arrow) to "TAPE DUB MODE" by pressing **CH ▲▼** or **TIME SCAN △▽**, then press **OK** or **TIME SCAN ▷** to set to "ON".



15 RETURN TO NORMAL SCREEN

Press **MENU**.

16 START PLAYER

Set the camcorder to its play mode.

NOTE:

If the camcorder is equipped with a superimpose/OSD disable feature then set its superimpose or display feature to OFF before pressing play.

17 START RECORDER

Set your VCR to its record mode.

- If you are using a Master Edit Control-equipped JVC camcorder, it can put the recorder automatically into Record mode. (Refer to camcorder's instruction manual.)

NOTES:

- *Be sure to set "TAPE DUB MODE" back to "OFF" when you finish editing.*
- *When "TAPE DUB MODE" is set to "ON" Active Video Calibration is deactivated in order to provide better picture quality edits.*
- *If you use an auxiliary input to connect a cable box or DBS receiver make sure that the correct input ("L-1", "F-1" or "S-VIDEO") is selected after you have finished editing (☞ step **3**, **6**, pg. 54).*

Edit To Or From Another VCR



Advantages Of S-VHS Editing

S-VHS allows you make high resolution video recordings when dubbing from one VCR to another.
You can edit from VHS to S-VHS, from S-VHS to VHS, or from S-VHS to S-VHS.

- From VHS to S-VHS: Record VHS playback signals in the S-VHS mode. Although the picture quality is inherently limited by the orignal VHS source material, the edited tape has better picture quality than those made by VHS-to-VHS editing.
- From S-VHS to VHS: Because the picture quality of the source material is very high, the edited tape has better picture quality than those made by VHS-to-VHS editing.
- From S-VHS to S-VHS: A high resolution copy is made of a high resolution original S-VHS tape with minimal picture degradation. This is the preferred method of video dubbing.

You can use your VCR as the player or the recorder.

1 MAKE CONNECTIONS

Connect an AV cable between the player's VIDEO OUT and AUDIO OUT connectors and the recorder's VIDEO IN and AUDIO IN connectors.

- If using another VCR with an S-VIDEO input or output connector, it is recommended to use the S-VIDEO connection to minimize picture degradation while editing.
- When using your VCR as the recorder and a monaural VCR as the player, connect the player's AUDIO OUT connector to the AUDIO IN L connector on the recorder.

2 LOAD CASSETTES

Insert the playback cassette into the player and the cassette to be recorded on into the recorder.

3 SET RECORDER'S INPUT MODE

Set to "AUX". With this VCR, press the **NUMBER** key "0" and/or **CH** to select depending on the connector being used – "L-1" for the rear AUDIO/VIDEO IN connector, or "F-1" for the front AUDIO/VIDEO IN connector.

NOTE:

*If you use your VCR as the recorder and have connected another VCR to your VCR's S-VIDEO IN connector, you need to set "REAR AUX INPUT" to "S-VIDEO" at the Function screen. Follow steps **4 – 6** from the "Edit From A Camcorder" section (☞ pg. 54 – 55).*

4 ENGAGE TAPE DUBBING MODE

Follow steps **12** – **14** from the "Edit From A Camcorder" section (☞ pg. 55).

5 START PLAYER

Set to its play mode.

NOTE:

*If the player is equipped with a superimpose/OSD disable feature then set "SUPERIMPOSE" to OFF before pressing **PLAY** (☞ pg. 29).*

6 START RECORDER

Set to its record mode.

NOTES:

- *Be sure to set "TAPE DUB MODE" back to "OFF" when you finish editing.*
- *When "TAPE DUB MODE" is set to "ON" Active Video Calibration is deactivated in order to provide better picture quality edits.*
- *If you use an auxiliary input to connect a cable box or DBS receiver make sure that the correct input ("L-1", "F-1" or "S-VIDEO") is selected after you have finished editing (☞ step **6**, page 54).*

Audio Dubbing



Audio dubbing replaces the normal audio sound of a previously recorded tape with a new soundtrack. Use your VCR as the recorder.



1 MAKE CONNECTIONS

Connect an audio component to the AUDIO IN L + R connectors on the VCR's front panel. *When connecting monaural equipment, use only the VCR's AUDIO IN L connector.

2 SET INPUT MODE

Press the remote control's **NUMBER** key "0" and **CH** so that "F-1" appears in place of a channel number.

- Be sure to select "FRONT S-VIDEO" or "FRONT VIDEO" at the AUX Input Screen. (To select the correct AUX input connector, follow steps **4** – **6**, **15** from the "Edit From A Camcorder" section, ☞ pg. 54.)

3 LOCATE START POINT

Press **PLAY** to start playback of the tape in your VCR, and press **PAUSE** when you find the point where you want to start dubbing.

4 ENGAGE AUDIO DUBBING

Press **A. DUB**.

- Your VCR enters the Audio Dubbing Pause mode. (◌ blinks, ▷ and ▒ light up on the front display panel.)

5 START DUBBING

Engage the audio component's Play mode, then press **PLAY** to start the tape in your VCR. Audio dubbing begins at this point.

- ◌ blinks and ▷ is displayed on the front display panel.
- To stop dubbing temporarily, press **PAUSE**. Press **PLAY** to resume dubbing.

6 END AUDIO DUBBING

Press **STOP** to stop the tape in your VCR, and engage the audio component's Stop mode.

NOTES:

- *When monitoring the sound during Audio Dubbing, the normal soundtrack is automatically selected. If you wish to hear the Hi-Fi or mixed sound (Hi-Fi + Normal soundtracks), refer to the "Select The Soundtrack" section (☞ pg. 30) and select the soundtrack you wish to hear.*
- *Audio dubbing stops automatically when the counter reaches "0:00:00", and the VCR enters the Play mode. Check the counter reading before dubbing.*
- *Audio dubbing is also possible using the rear AUDIO IN connectors. When using these connectors, be sure to select "REAR S-VIDEO" or "REAR VIDEO" at the Aux Input screen. To select the correct Aux Input connector, follow steps **4** – **6**, **15** from the "Edit From A Camcorder" section ☞ pg. 54.*
- *Audio dubbing cannot be performed on a cassette that has had its record safety tab removed.*
- *When playing back an audio-dubbed tape, refer to the "Select The Soundtrack" section (☞ pg. 30) to select the soundtrack you wish to hear.*
- *Picture may be distorted during Audio Dubbing Pause.*
- *It may be unlawful to record or play back copyrighted material without the consent of the copyright owner.*

Insert Editing





Insert editing replaces part of the recorded scene with new material. Both the picture and Hi-Fi audio soundtrack are replaced with new ones, while the normal audio soundtrack remains unchanged. If you wish to change the normal audio track as well, use the audio dubbing function simultaneously. Use your VCR as the recorder.



1 MAKE CONNECTIONS

Connect the player's VIDEO OUT and AUDIO OUT connectors to your VCR's VIDEO IN and AUDIO IN on the front panel.

2 SET INPUT MODE

Press the **NUMBER** key "0" and **CH** so that "F-1" appears in place of a channel number.

- Be sure to select the correct AUX input connector at the Aux Input screen. (To select the correct AUX input connector, follow steps **4 – 6, 15** from the "Edit From A Camcorder" section ☞ pg. 54).

3 LOCATE END POINT

Load the recording cassette into your VCR, and play it back to determine the edit-out point (the end of the segment to be replaced) using the **SHUTTLE** ring or the **JOG** dial or pressing **TIME SCAN** I◄◄ ►►I and **PAUSE**.

- To use the **JOG** dial/**SHUTTLE** ring, first press the **JOG/SHUTTLE** button on the remote control so that the button lights up.

4 RESET THE COUNTER

Press **C.RESET** to change the counter display to "0:00:00".

5 LOCATE START POINT

Determine the edit-in point (the beginning of the segment to be replaced) using the **SHUTTLE** ring or the **JOG** dial or pressing **TIME SCAN** I◄◄ ►►I and **PAUSE**.

- Be sure to engage the Still mode at the edit-in point.





6 ENGAGE INSERT EDITING

Press **INSERT**.

- Your VCR enters the Insert-Pause mode. (◌, ▷ and ⬚ light up on the front display panel.)
- The TV screen changes from the still picture to the input source you are going to record.

7 START EDITING

Load the source cassette and play back the segment that is to be inserted. When you reach the start of the section of the source tape that you wish to insert, press **PLAY** to start the tape in your VCR; Insert Editing begins at this point.

- ▷ and ◌ are displayed on the front display panel.

8 END INSERT EDITING

At counter "0:00:00", Insert Editing will stop automatically while the tape continues running in the Play mode. if you wish to stop Insert Editing before the specified edit-out point, press **C.RESET**.

FOR AV INSERT EDITING

If you want to replace the picture, Hi-Fi audio soundtrack and normal audio soundtrack all at the same time...
In step **6** above, after you press **INSERT**, press **A. DUB.** also.
(◌ and ▷ blink and ⬚ lights up on the display panel.)

NOTES:

- *Insert editing is not possible with cassettes whose safety tab has been removed.*
- *In insert editing, the recording speed (SP/EP) is determined by the previous recording to be replaced. If the previous recording's speed changes within a single edit, the inserted picture will be distorted at the switching point.*
- *A small portion of the recording which precedes an insert edit may become erased.*
- *Insert Editing is also possible using the rear connectors. When using these connectors, be sure to select the correct AUX input connector at the Aux Input screen. To select the correct AUX input connector, follow steps **4 – 6, 15** from the "Edit From A Camcorder" section, ☞ pg 54.*



TV Multi-Brand Remote Control

The VCR's remote control can control several functions on JVC remote control TVs and on the brands of remote control TVs listed below.

1 TURN ON THE TV

Turn the power on using the TV's remote control.

2 SET REMOTE CONTROL MODE

Set the **VCR/TV/CABLE/DBS** switch on the VCR's remote control to TV.

3 SET TV BRAND CODE

Refer to the chart below. While holding down **POWER** on the VCR's remote control, enter your TV's brand code using the **NUMBER** keys, then press **STOP**. Follow the example shown at bottom left.

- Once you have set the remote control to operate the TV, you don't have to repeat this step until you replace your remote control's batteries.
- PANASONIC has two codes. If the TV does not function with one code, try entering the other.

4 OPERATE TV

First, press **POWER** on the remote to see if the TV's power goes off as it should. If it does, try other operations.

- The **POWER**, **TV/VCR**, **TV CH +/–**, **TV VOL +/–**, **AUDIO MONITOR** (TV Muting) and **NUMBER** keys on the remote can all be used to operate the TV. *For some brands of TV, you must press **ENTER** after having pressed the **NUMBER** keys.
- To return the remote to VCR control, set the **VCR/TV/CABLE/DBS** switch to VCR.

TV BRAND NAME	BRAND CODE
JVC	01
MAGNAVOX	02
MITSUBISHI	03
PANASONIC	04, 11
RCA	05
SHARP	06
SONY	07
TOSHIBA	08
ZENITH	09
HITACHI	10
SAMSUNG	12
SANYO	13
SEARS	13

NOTE:

Depending on the type of TV, there may be cases where some or all functions cannot be operated using the remote control.

(Ex.) To set remote control to RCA 05:



Cable Box Multi-Brand Remote Control

The VCR's remote control can control functions on the brands of cable boxes listed below. Some cable box brands have more than one code. If your cable box does not function with a specified code, try other codes.



1 TURN ON THE CABLE BOX

Turn the power on using the cable box's remote control.

2 SET REMOTE CONTROL MODE

Set the **VCR/TV/CABLE/DBS** switch on the VCR's remote control to CABLE/DBS.

3 ENTER CABLE BOX BRAND

While holding down **POWER** on the VCR's remote control, use the **NUMBER** keys to enter the cable box brand number from the chart at bottom left and then press **STOP**. Follow the example shown below.

- Once you have set the remote control to operate the cable box, you don't have to repeat this step until you replace the remote control's batteries.

4 OPERATE CABLE BOX

First, press **POWER** to see if the cable box's power goes off as it should. If it does, try other functions (**TV CH +/–** and the **NUMBER** keys can be used to operate the cable box).

- For some brands of cable box, you must press **ENTER** after having pressed the **NUMBER** keys.
- To return the remote to VCR control, set the **VCR/TV/CABLE/DBS** switch to VCR.

CABLE BOX BRAND NAME	BRAND CODE
ARCHER	01, 05, 17
CABLETENNA	01, 17
CABLEVIEW	15, 16, 17, 21, 25
CITIZEN	15, 16, 17, 21, 25
CURTIS	02, 08
DIAMOND	01, 17
EASTERN	19
GC BRAND	15, 16, 17, 21, 25
GEMINI	15
GENERAL INSTRUMENTS	01, 04, 06, 11, 12, 15
HAMLIN	10, 18, 19, 23
JASCO	15
JERROLD	01, 04, 06, 11, 12, 15
NOVAVISION	02, 08
OAK	07, 20
PANASONIC	13, 14
PULSER	15, 16, 17, 21, 25
RCA	13, 14
REGAL	10, 18, 19, 23
REGENCY	19
REMBRANDT	01, 16, 17
SAMSUNG	05, 16, 24
SCIENTIFIC ATLANTA	02, 08
SIGMA	07, 20
SL MARX	05, 16, 17, 24, 25
SPRUCER	13, 14
STARGATE	05, 15, 16, 17, 21, 24, 25
TELEVIEW	05, 16, 24
TOCOM	01, 04, 16
UNIKA	01, 17
UNIVERSAL	16, 17, 25
VIDEOWAY	03, 09, 22
ZENITH	03, 09, 22

NOTES:

- *You must set the cable box brand for your remote control and the cable box brand for your Controller (☞ pg. 18) separately. The list of cable box brands that can be controlled by your remote control is different from the list of brands that can be controlled by your controller.*
- *Depending on the type of cable box, there may be cases where some or all functions cannot be operated using the remote control.*
- *It's not possible to set the remote control for both your cable box and a DBS receiver at the same time. You can only set the remote control to operate one of these units at a time.*

(Ex.) To set remote control to RCA 14:



DBS Receiver Multi-Brand Remote Control

The VCR's remote control can control functions on the brands of DBS (Direct Broadcast Satellite) receivers listed below.



1 TURN ON THE DBS RECEIVER

Turn the power on using the DBS receiver's remote control.

2 SET REMOTE CONTROL MODE

Set the **VCR/TV/CABLE/DBS** switch on the VCR's remote control to CABLE/DBS.

3 ENTER DBS RECEIVER BRAND

While holding down **POWER** on the VCR's remote control, use the **NUMBER** keys to enter the DBS receiver brand number from the chart below and then press **STOP**. Follow the example shown at bottom left.

- Once you have set the remote control to operate the DBS receiver, you don't have to repeat this step until you replace the remote control's batteries.

4 OPERATE DBS RECEIVER

First, press **POWER** to see if the DBS receiver's power goes off as it should. If it does, try other functions (**TV CH +/–** and the **NUMBER** keys can be used to operate the DBS receiver).

- For some brands of DBS receiver, you must press **ENTER** after having pressed the **NUMBER** keys.
- To return the remote to VCR control, set the **VCR/TV/CABLE/DBS** switch to VCR.

DBS BRAND NAME	BRAND CODE
JVC (DISH Network)	51
ECHOSTAR (DISH Network)	51
PRIMESTAR	50
SONY (DSS)	41
RCA (DSS)	40

(Ex.) To set remote control to JVC 51:



NOTES:

- *You must set the DBS receiver brand for your remote control and the DBS receiver brand for your Controller (☞ pg. 21) separately.*
- *Depending on the type of DBS receiver, there may be cases where some or all functions cannot be operated using the remote control.*
- *It's not possible to operate a DBS receiver that is not equipped with a remote control sensor.*
- *Though ECHOSTAR has a number of different remote codes, this remote control is applicable only to one of those codes preset at the factory.*
- *It's not possible to set the remote control for both your DBS receiver and a cable box at the same time. You can only set the remote control to operate one of these units at a time.*



Child Lock

This feature allows you to prevent the operation of the VCR.

1 TURN VCR POWER ON

Press **POWER**.

2 ENGAGE CHILD LOCK

Press and hold **POWER** on the remote control until the Child Lock indicator ("—") appears on the front display panel.

- Power turns OFF and the VCR cannot be turned on from the **POWER** button on the front panel.
- To cancel Child Lock, press and hold **POWER** on the remote until the VCR turns on. During timer recording, pressing **TIMER** also cancels Child Lock.

NOTES:

- *When Child Lock is engaged, make sure to keep the remote control out of the reach of children.*
- *Timer recording of programs that were previously set can be performed while the Child Lock is engaged. The feature remains in effect after the recording is finished.*

Control Two JVC VCRs

The remote control is capable of controlling two JVC VCRs independently; one set to respond to your remote control's **A** code control signals and another set to respond to **B** code control signals. The remote control is preset to send **A** code signals because your VCR is initially set to respond to **A** code signals. You can easily modify your VCR to respond to **B** code signals.

1 UNPLUG VCR'S POWER CORD

Unplug from the AC outlet.

2 SET REMOTE CONTROL CODE

While holding down **A/B** on the remote control, press the **NUMBER** key "2" and then press **STOP**.

3 PLUG IN POWER CORD

Plug back in to the AC outlet.

4 TURN VCR POWER ON

Press **POWER** on the remote.

The VCR will now respond only to B-code commands.
To set the VCR back to respond to A code signals, repeat the same procedure as shown above except pressing **NUMBER** key "1" instead of "2" in step **2**.
You can control two VCRs with the same remote control by switching the remote's code between A and B (☞ Step **2**), pressing "1" for A-code commands and "2" for B-code commands.





Back of VCR



J Terminal (JLIP(Joint Level Interface Protocol) Connector)

The J Terminal is used to connect the VCR to a personal computer or similar device to allow computerized control of the VCR during editing and certain other operations.

For further details consult your nearest JVC dealer.
U.S. customers can contact JVC directly toll free at 1-800-252-5722.

JLIP ID Number

Your VCR has its own JLIP ID number. This ID number must be unique when your VCR is connected to another device via its J terminal. The ID Number is preset to "1" at the factory. You can change this number to any number between "1" and "99".
If it is necessary to change the JLIP ID number perform the following steps.

1 ACCESS MAIN MENU SCREEN

Press **MENU**.

2 ACCESS INITIAL SET SCREEN

Move the highlight bar (arrow) to "INITIAL SET" by pressing **CH** ▲▼ or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

3 ACCESS JLIP ID NO. SET SCREEN

Move the highlight bar (arrow) to "JLIP ID NO. SET" by pressing **CH** ▲▼ or **TIME SCAN** △▽, then press **OK** or **TIME SCAN** ▷.

4 SET JLIP ID NUMBER

Press **NUMBER** key to enter the desired ID number, then press **OK**.



5 RETURN TO NORMAL SCREEN

Press **MENU**.

NOTES:

This VCR may not accept commands from your personal computer such as:

- *Power ON/OFF while the VCR is in the Timer mode.*
- *Power ON when there is no cassette inserted in the VCR.*

Before requesting service for a problem, use this chart and see if you can repair the trouble yourself. Small problems are often easily corrected, and this can save you the trouble of sending your VCR off for repair.

POWER

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
1. The power won't come on.	● The power cord is disconnected.	Connect the power cord.
2. The clock works, but the VCR's power won't come on.	● The TIMER mode is engaged with Auto Timer set to "OFF" (☞ pg. 45). ● The Child Lock mode is engaged.	Press **TIMER** to disengage. Press and hold **POWER** on the remote to disengage the mode (☞ pg. 63).
3. The remote control won't function.	● The batteries are discharged.	Replace the dead batteries with new ones.

TAPE TRANSPORT

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
1. The cassette gets stuck partway during loading, and is ejected.	● The cassette was inserted incorrectly.	Make sure the cassette's window is facing up, the rear label side is facing you and the arrow on the front of the cassette is pointing towards the VCR. Then insert the cassette.

PLAYBACK

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
1. The tape is running but the picture won't appear.	● If you're using the RF OUT connection (☞ pg. 6), the channel selector on the TV is set incorrectly. ● If you're using the AV connection (☞ pg. 6), the TV receiver is set to the wrong mode.	Set the channel selector to channel 3 or 4. Set the TV receiver to its AV mode.
2. Noise appears during visual search.	● This is normal.	
3. Breaks are noticeable in Hi-Fi soundtrack.	● Automatic tracking is engaged.	Disengage Auto Tracking and adjust the tracking manually (☞ pg. 26).
4. The playback picture is blurred or interrupted, even though TV broadcasts are clear.	● The video heads may be dirty.	The heads must be cleaned. Consult your JVC dealer.
5. The Hi-Fi soundtrack cannot be heard.	● The AUDIO MONITOR option was set incorrectly.	Set AUDIO MONITOR to "HI-FI" (☞ pg. 30).

RECORDING

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
1. Recording won't start.	● There's no cassette loaded. ● The loaded cassette has had its record safety tab removed.	Insert a cassette. Remove the cassette and cover the hole with adhesive tape, or load a cassette on which the record safety tab is intact.
2. TV broadcasts won't record properly.	● The VCR has been set to its AUX mode by mistake.	Set the VCR to the appropriate channel.
3. Tape-to-tape editing won't work.	● The VCRs or the camcorder and the VCR have been incorrectly connected. ● The power to one or more of the units has not been turned on. ● The recorder's input mode has been set incorrectly.	Refer to the directions and the illustration under "Edit To Or From Another VCR" (☞ pg. 56) or "Edit From A Camcorder" (☞ pg. 54) and properly connect the units. Make sure the power to all units is on. Select the recorder's appropriate input mode.

CONTINUED ON NEXT PAGE

TIMER RECORDING

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
1. Timer recording won't work.	● The clock and/or the timer have been set incorrectly. ● The timer is not engaged. ● The VCR has not been set up properly.	Set the clock and/or timer correctly. Press **TIMER** and check to make sure that ◴ appears on the front display panel. Re-perform the set-up procedures. Make sure you have compensated for Guide Channel and VCR or cable box channel number mismatches (☞ pg. 48).
2. Timer programming won't work.	● Timer recording is in progress.	Timer programming can't be performed when timer recording is in progress. Wait until it finishes.
3. ◴ and 📼 on the front display panel won't stop blinking.	● The timer is engaged but there's no cassette loaded.	Load a cassette with the record safety tab intact, or with the hole covered with adhesive tape.
4. The cassette is automatically ejected, and ◴ and 📼 on the front display panel won't stop blinking.	● The loaded cassette has had its record safety tab removed.	Remove the cassette and cover its hole with adhesive tape, or replace it with a cassette on which the safety tab is intact.
5. ◴ blinks for 10 seconds and the timer mode is disengaged.	● **TIMER** has been pressed when there are no programs in memory, or the timer record program information has not been programmed correctly.	Check the programmed data and re-program as necessary, then press **TIMER** again.
6. The cassette is automatically ejected, the power shuts off and ◴ and 📼 won't stop blinking.	● The end of tape was reached during timer recording.	The program may not have been recorded in its entirety. Next time make sure you have enough time on the tape to record the entire program.
7. Cable channels are not automatically switched during timer recording.	● The Controller is not properly connected to the VCR. ● The output channel selected in the Cable Box Set screen is incorrect. ● The cable box's power is off.	Connect the Controller correctly (☞ pg. 16). After confirming your cable box's output channel number, re-access the Cable Box Set screen and select the correct number (☞ pg. 17). Make sure the power is on before timer recording starts.
8. Satellite channels are not automatically switched during timer recording.	● The Controller is not properly connected to the VCR. ● The output channel selected in the DBS Receiver Set screen is incorrect. ● The VCR is not set correctly to control the DBS Receiver ● The DBS receiver's power is off.	Connect the Controller correctly (☞ pg. 19). After confirming your DBS receiver's output channel number, re-access the DBS Receiver Set screen and select the correct number (☞ pg. 20). Set the correct DBS Receiver brand code (☞ pg. 21). Make sure the power is on before timer recording starts.
9. Timer recording begins as scheduled, but the channel is always incorrect.	● Even though you don't use an external Cable Box, "CABLE BOX SET" is set to "ON".	Set "CABLE BOX SET" to "OFF" (☞ pg. 17).
10. We moved, and now VCR Plus+ doesn't work properly.	● The receivable stations in the new area are received on different channels than those in the previous area.	Re-perform the VCR Plus+ setup procedure (☞ pg. 48).
11. "PROGRAM FULL" is displayed on the screen.	● All 8 programs of the VCR's timer memory are used.	Wait until a space in memory clears, or cancel unnecessary program information (☞ pg. 52).

OTHER PROBLEMS

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
1. When scanning channels, some of them are skipped over.	● Those channels have been preset to be skipped.	If you need the skipped channels, restore them (☞ pg. 15).
2. The channel can't be changed.	● Recording is in progress.	Press **PAUSE** to pause the recording, change channels, then press **PLAY** to resume recording.
3. The remote control won't operate my TV or cable box or DBS receiver.	● The remote control brand setting is incorrect.	Re-set the remote control to the correct brand (☞ pg. 60 or 61 or 62).
4. Even though Auto or Semi-Auto clock setting has been selected, the clock is incorrect.	● The clock setting data received from the Host Channel is incorrect.	Select a different Host Channel during the Semi-Auto setting procedure (☞ pg. 12), or perform the Manual setting procedure (☞ pg. 13).

ATTENTION
This VCR contains microcomputers. External electronic noise or interference can cause microcomputer to malfunction. If the VCR does not operate correctly switch its power off and unplug the power cord from the AC supply. Wait for a while and then plug the power back in. Eject and check the condition of the cassette. If everything appears normal resume operating the VCR as usual.

PLAYBACK

Q. What happens if the end of the tape is reached during playback or search?
A. The tape is automatically rewound to the beginning.

. . . . . .

Q. Can the VCR indefinitely remain in the still mode?
A. No. It stops automatically after 5 minutes to protect the heads.

. . . . . .

Q. During search, still and frame-by-frame playback, the picture is intermittent. What's the cause?
A. Picture loss occurs when these types of playback are attempted with a tape recorded in LP mode. Pressing **PLAY** to return to normal playback will restore the picture.

. . . . . .

Q. When returning from multi-speed search to normal playback, the picture is disturbed. Should I be concerned about this?
A. No, it is normal.

. . . . . .

Q. When playing back programs that have been timer-recorded with consecutive times (such one program from 8:00 to 9:00 and another one from 9:00 to 10:00), the picture and sound become momentarily distorted at the point where the first program ends and the second program begins. Is this a malfunction?
A. No. This is normal.

. . . . . .

Q. Other than preventing further recording, what effect does removing the safety tab have?
A. It disables marking of index codes.

. . . . . .

Q. Sometimes, during Index Search, the VCR can't find the program I want to see. Why not?
A. There may be index codes too close together.

. . . . . .

Q. During playback, on-screen operational indicators sometimes jitter. Why does this happen?
A. If the condition of the tape being played back is not good, jittering of the video (including on-screen indicators) may occur.

RECORDING

Q. When I pause and then resume a recording, the end of the recording before the pause is overlapped by the new recording. Why does this happen?
A. This is normal. It reduces distortion at the pause and resume points.

. . . . . .

Q. Can the VCR indefinitely remain in the Record-Pause mode?
A. No. The VCR automatically goes to its Stop mode after 5 minutes to protect the heads. When paused during Instant Timer Recording (ITR), the VCR shuts off automatically after 5 minutes.

. . . . . .

Q. What happens if the tape runs out during recording?
A. The VCR automatically rewinds it to the beginning.

TIMER RECORDING

Q. REC and ◴ remain lit on the front display panel. Is there a problem?
A. No. This is a normal condition for a timer recording in progress.

. . . . . .

Q. Can I program the timer while I'm watching a tape or a TV broadcast?
A. Yes, but while you are setting the timer you won't see the tape's or broadcast program's picture as it is replaced by the on-screen menu. The audio from the tape or broadcast program will be present during the setting of the timer.

List Of Terms

This guide serves as a quick way to locate frequently used terms and on-screen display names.

A

A/B Code 63
Active Video Calibration 36
Add Channel 15
Audio Dubbing 57
Audio Monitor 30
Auto Channel Setting 14
Auto Daylight Saving Time 12
Auto SP→EP Timer 53
Auto Timer 53
Automatic Tracking 26
Aux Input 54
AV Compu Link Playback 34
AV Connection 6

B

Band 14

C

Cable Box 16
Cable Box Brand Setting 18
Cable Box Controller 16
Cancel Program 52
Cassette Adapter 22
Check Program 52
Child Lock 63
Commercial Advance 32
Connection to TV 6
Contents 5
Counter Reset 27

D

DBS Receiver 19
DBS Receiver Brand Setting 21
DBS Receiver Controller 19
Delete Channel 15
Digital R3 35
Digital TBC/NR 35

E

Editing 54
Express Timer Programming 50
Express Timer Recording 50

F

Frame-by-Frame Playback 24

G

Guide Channel Setting 49

H

Host Channel Selection 12

I

Index Search 26
Insert Cassette 22
Insert Editing 58
Instant ReView 27
ITR (Instant Timer Recording) 45

J

JLIP Terminal 64
JOG Dial 25

L

Language Selection 10

M

Main Menu 10
Manual Channel Setting 15
Manual Clock Setting 13
Manual Tracking 26
MBR (Multi-Brand Remote) Code Setting 60
Movie Advance 31

N

Next-Function Memory 27

O

On-Screen Display 29

P

PBS Channel 8
Playback 22
Plug & Play 8
Pro-Slow 24

R

Record Safety Tab 23
Recording 23
Repeat Playback 27
Reverse Motion Playback 24
Reverse Slow Motion Playback 24
RF Connection 6

S

SAP (Second Audio Program) 43
Second Audio 43
Select Cable Box Output Channel 17
Select DBS Receiver Output Channel 20
Semi-Auto Clock Setting 12
SHUTTLE ring 22
Skip Search 26
Slow Motion Playback 24
Specifications 73
Still Picture Playback 24
Superimpose 29
S-VHS (Super VHS) 41
S-VHS ET 42
S-Video Connection 7

T

Tape Position Indicator 27
Tape Speed Setting 23
TimeScan 38
Time Zone Selection 13
Tuner Setting 14

V

Variable-Speed Search 25
VCR Plus+ Timer Programming 46
VCR Plus+ Timer Recording 46
Video Stabilizer 28

FRONT VIEW



Attach the provided connector cover when you do not use the front panel connectors.



Open the lid to access covered buttons/connectors.

❶ Power On/Off Button (☞ pg. 10)
❷ S-VHS ET Button (☞ pg. 42)
❸ MENU Button (☞ pg. 10)
❹ STOP/EJECT Button (☞ pg. 22)
❺ Channel [CH] ▲▼ Button (☞ pg. 23)
❻ Cassette Loading Slot
❼ PLAY Button (☞ pg. 22)
❽ DIGITAL TBC/NR Button (☞ pg. 35)
❾ S-VHS/VIDEO/AUDIO Input Connectors (☞ pg. 54)
❿ INSERT Button (☞ pg. 58)
⓫ Audio Dubbing [A. DUB] Button (☞ pg. 57)
⓬ Front Display Panel (☞ pg. 71)
⓭ Rewind [REW] Button (☞ pg. 22)
⓮ OK Button (☞ pg. 10)
⓯ Record [REC] Button (☞ pg. 23)
⓰ Fast-Forward [FF] Button (☞ pg. 22)
⓱ Remote Control Sensor
⓲ PAUSE Button (☞ pg. 24)

REAR VIEW



❶ Power Cord (☞ pg. 6)
❷ J Terminal (JLIP(Joint Level Interface Protocol) Connector) (☞ pg. 64)
❸ VIDEO/AUDIO Output Connectors (☞ pg. 6)
❹ VIDEO/AUDIO Input Connectors (☞ pg. 56)
❺ ANTENNA IN Connector (☞ pg. 6)
❻ S-Video (S-VHS) Output Connector (☞ pg. 7)
❼ S-Video (S-VHS) Input Connector (☞ pg. 56)
❽ CABLE BOX Controller Connector (☞ pg. 16, 19)
❾ REMOTE PAUSE/AV COMPULINK Connector
- REMOTE PAUSE Connector (☞ pg. 54)
- AV COMPU-LINK Connector (☞ pg. 31)

❿ Channel 3/4 Switch (☞ pg. 6)
⓫ TV OUT Connector (☞ pg. 6)

FRONT DISPLAY PANEL



❶ Audio Level Indicator ☞ pg. 44
❷ Symbolic Mode Indicators

PLAY: FF/REW VARIABLE SHUTTLE SEARCH:	▷	STILL: SLOW:	▷
		RECORD:	○
		RECORD PAUSE:	○
AUDIO DUBBING:			
AUDIO DUBBING PAUSE:			
INSERT:			
INSERT PAUSE:			
AUDIO DUBBING INSERT:			
AUDIO DUBBING INSERT PAUSE:			

❸ Timer Mode Indicator
❹ S-VHS Indicator (☞ pg. 41)
❺ Tape Speed Indicators (☞ pg. 23)
❻ Child Lock Indicator (☞ pg. 63)
❼ Tape Remaining Time Indicator (☞ pg. 40)
❽ "Cassette Loaded" Mark
❾ VCR Mode Indicator (☞ pg. 40)
❿ Channel Display ["L-1" and "F-1" for AUX mode]
Counter Display (☞ pg. 8)
Clock Display (☞ pg. 8)

REMOTE CONTROL



Buttons with a small dot on the left side of the name can also be used to operate your TV with the **VCR/TV/CABLE/DBS** switch set to TV. ☞ pg. 60

❶ VCR/TV/CABLE/DBS Switch (☞ pg. 60)
❷ TV/VCR Button (☞ pg. 40)
❸ Instant REVIEW Button (☞ pg. 27)
❹ NUMBER Buttons (☞ pg. 23, 46)
❺ DBS Button (☞ pg. 51)
❻ CANCEL Button (☞ pg. 52)
Counter [C.] RESET Button (☞ pg. 27)
❼ STOP +/– Button (☞ pg. 50)
❽ START +/– Button (☞ pg. 50)
❾ PROG. Button (☞ pg. 38, 50)
❿ PROG. CHECK Button (☞ pg. 52)
⓫ Rewind [REW] Button (☞ pg. 22)
⓬ Record [REC] Button (☞ pg. 23)
⓭ STOP Button (☞ pg. 22)
⓮ TIME SCAN △▽ Button (☞ pg. 10)
TV Channel [CH] +/– Button (☞ pg. 60, 61, 62)
⓯ MENU Button (☞ pg. 10)
⓰ A/B Code Button (☞ pg. 63)
⓱ JOG Dial (☞ pg. 14)
⓲ AUDIO MONITOR Button (☞ pg. 30)
TV Muting Button (☞ pg. 60)
⓳ POWER On/Off Button (☞ pg. 10)
⓴ ENTER Button (☞ pg. 23)
On-Screen Display [OSD] Button (☞ pg. 29)
㉑ DISPLAY Button (☞ pg. 27)
㉒ DAILY Timer Recording Button (☞ pg. 47, 51)
㉓ WEEKLY Timer Recording Button (☞ pg. 47, 51)
㉔ "AUX" Mode Select Button (☞ pg. 54)
㉕ TIMER Button (☞ pg. 47, 51)
㉖ DATE +/– Button (☞ pg. 50)
㉗ Channel [CH] +/– Button (☞ pg. 23, 51)
㉘ SKIP SEARCH Button (☞ pg. 26, 30)
㉙ Recording Speed [SP/EP] Button (☞ pg. 23)
㉚ PLAY Button (☞ pg. 22)
㉛ Fast-Foward [FF] Button (☞ pg. 22)
㉜ PAUSE Button (☞ pg. 24)
㉝ TIME SCAN ⏮ ⏭ (◁ ▷) Button (☞ pg. 24, 38)
TV Volume [VOL] +/– Button (☞ pg. 60)
㉞ OK Button (☞ pg. 10)
㉟ JOG/SHUTTLE Button (☞ pg. 22)
㊱ SHUTTLE Ring (☞ pg. 22)

Installing Batteries

1 Open the battery compartment cover.
2 Insert 2 "AA"-size batteries (provided) in the direction indicated under the battery cover.
3 Replace the cover.



How To Use

The remote control can operate most of your VCR's functions.
1 Point the remote control toward the sensor window. (☞ pg. 70)
2 Press the appropriate operation button.
3 The maximum operating distance of the remote control is about 8 m.

NOTES:

- *This remote control can also operate various brands of TVs, Cable Boxes and DBS Receivers. For instructions, ☞ pg. 60 – 62.*
- *If the remote control doesn't work properly, remove its batteries, wait a short time, replace the batteries and then try again.*

GENERAL

Power requirement	: AC 120 V~ , 60 Hz
Power consumption	
Power on	: 28 W
Power off	: 3 W
Temperature	
Operating	: 5°C to 40°C (41°F to 104°F)
Storage	: –20°C to 60°C (–4°F to140°F)
Operating position	: Horizontal only
Dimensions (W x H x D)	: 437 x 109 x 340 mm (17-1/4" x 4-5/16" x 13-7/16")
Weight	: 4.8 kg (10.6 lbs)
Format	: S-VHS/VHS NTSC standard
Maximum recording time	
SP	: 210 min. with ST-210 video cassette
EP	: 630 min. with ST-210 video cassette

VIDEO/AUDIO

Signal system	: NTSC-type color signal and EIA monochrome signal, 525 lines/60 fields
Recording/ Playback system	: DA-4 (Double Azimuth) head helical scan system
Signal-to-noise ratio	: 45 dB
Horizontal resolution	: 240 lines (VHS) : 400 lines (S-VHS)
Frequency range	
Normal audio	: 70 Hz to 10,000 Hz
Hi-Fi audio	: 20 Hz to 20,000 Hz
Input/Output	: RCA connectors (IN x 2, OUT x 1) : S-Video connectors (IN x 2, OUT x 1)

TUNER

Tuning system	: Frequency-synthesized tuner
Channel coverage	
VHF	: Channels 2–13
UHF	: Channels 14–69
CATV	: 113 Channels
RF output	: Channel 3 or 4 (switchable; preset to Channel 3 when shipped) 75 ohms, unbalanced

TIMER

Clock reference	: Quartz
Program capacity	: 1-year programmable timer/ 8 programs
Memory backup time	: Approx. 10 min.

ACCESSORIES

Provided accessories	: RF cable (F-type), Infrared remote control unit, “AA” battery x 2, Audio/Video Cable, S-Video cable (4-pin), Controller, Connector cover (for front panel connectors)

Specifications shown are for SP mode unless otherwise specified.
E. & O.E. Design and specifications subject to change without notice.

HOW TO LOCATE YOUR JVC SERVICE CENTER

TOLL FREE: 1-800-252-5722

Dear customer:

In order to receive the most satisfaction from your purchase, read the instruction booklet before operating the unit. In the event that repair is necessary, or for the address nearest your location, please refer to the factory service center list below or within the Continental United States, call 1-800-252-5722 for your authorized servicer. Remember to retain your Bill of Sale for Warranty Service.

— JVC

JVC SERVICE & ENGINEERING COMPANY OF AMERICA
DIVISION OF US JVC CORP.

FACTORY SERVICE CENTER LOCATIONS

107 Little Falls Road
Fairfield, NJ 07004-2105
(973) 808-9279

1500 Lakes Parkway
Lawrenceville, GA 30243-5857
(770) 339-2522

705 Enterprise Street
Aurora, IL 60504-8135
(630) 851-7855

5665 Corporate Avenue
Cypress, CA 90630-4727
(714) 229-8011

10700 Hammerly Boulevard, Suite 110
Houston, TX 77043-2310
(713) 935-9331

2969 Mapunapuna Place, Suite 101
Honolulu, HI 96819-2000
(808) 833-5828

230 Eliot Street
Ashland, MA 01721-2377
(508) 881-5923

8192 W State Road 84
Davie, FL 33324-4611
(954) 472-1960

890 Dubuque Avenue
South San Francisco, CA 94080-1804
(415) 871-2666

Sophisticated electronic products may require occasional service. Just as quality is a keyword in the engineering and production of the wide array of JVC products, service is the key to maintaining the high level performance for which JVC is world famous. The JVC service and engineering organization stands behind our products.

NATIONAL HEADQUARTERS
JVC SERVICE & ENGINEERING COMPANY OF AMERICA
DIVISION OF US JVC CORP.
107 Little Falls Road
Fairfield, NJ 07004-2105

If you ship the product...

Pack your JVC unit in the original carton or one of equivalent size and strength. Enclose, with the unit, a letter stating the problem or symptom that exists and also a copy of the receipt or bill of sale you received when you purchased your JVC unit. Print your home return address on the outside and the inside of the carton. Send to the appropriate JVC Factory Service Center as listed above.

ACCESSORIES

To purchase accessories for your JVC product, you may contact your local JVC Dealer.
Or from the 48 Continental United States call toll free: 1-800-882-2345.

Don't service it yourself.

CAUTION

To prevent electrical shock, do not open the cabinet. No user serviceable parts inside.
Refer servicing to qualified service personnel.

LIMITED WARRANTY

CONSUMER VIDEO 1-90

JVC COMPANY OF AMERICA warrants this product and all parts thereof, except as set forth below ONLY TO THE ORIGINAL PURCHASER AT RETAIL to be FREE FROM DEFECTIVE MATERIALS AND WORKMANSHIP from the date of original retail purchase for the period as shown below. ("The Warranty Period")

PARTS	LABOR
1 YR	**90** DAYS

THIS LIMITED WARRANTY IS VALID ONLY IN THE FIFTY (50) UNITED STATES, THE DISTRICT OF COLUMBIA AND IN COMMONWEALTH OF PUERTO RICO.

WHAT WE WILL DO:
If this product is found to be defective, JVC will repair or replace defective parts at no charge to the original owner. Such repair and replacement services shall be rendered by JVC during normal business hours at JVC authorized service centers. Parts used for replacement are warranted only for the remainder of the Warranty Period. All products and parts thereof may be brought to a JVC authorized service center on a carry-in basis except for Television sets having a screen size 25 inches and above which are covered on an in-home basis.

WHAT YOU MUST DO FOR WARRANTY SERVICE:
Return your product to a JVC authorized service center with a copy of your bill of sale. For your nearest JVC authorized service center, please call toll free: (800) 252-5722.

If service is not available locally, box the product carefully, preferably in the original carton, and ship, insured, with a copy of your bill of sale plus a letter of explanation of the problem to the nearest JVC Factory Service Center, the name and location of which will be given to you by the toll-free number.

If you have any questions concerning your JVC Product, please contact our Customer Relations Department.

WHAT IS NOT COVERED:
This limited warranty provided by JVC does not cover:
1. Products which have been subject to abuse, accident, alteration, modification, tampering, negligence, misuse, faulty installation, lack of reasonable care, or if repaired or serviced by anyone other than a service facility authorized by JVC to render such service, or if affixed to any attachment not provided with the products, or if the model or serial number has been altered, tampered with, defaced or removed;
2. Initial installation and installation and removal for repair;
3. Operational adjustments covered in the Owner's Manual, normal maintenance, video and audio head cleaning;
4. Damage that occurs in shipment, due to act of God, and cosmetic damage;
5. Signal reception problems and failures due to line power surge;
6. Video Pick-up Tubes/CCD Image Sensor, Cartridge, Stylus (Needle) are covered for 90 days from the date of purchase;
7. Accessories;
8. Batteries (except that Rechargeable Batteries are covered for 90 days from the date of purchase); from the date of purchase);

There are no other express warranties except as listed above.

THE DURATION OF ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN.

JVC SHALL NOT BE LIABLE FOR THE LOSS OF USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, WHETHER DIRECT, INCIDENTAL OR CONSEQUENTIAL (INCLUDING, WITHOUT LIMITATION, DAMAGE TO TAPES, RECORDS OR DISCS) RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE, ARE LIMITED TO THE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion of incidental or consequential dameges or limitations on how long an implied warranty lasts, so these limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

JVC COMPANY OF AMERICA
DIVISION OF US JVC CORP.

41 Slater Drive
Elmwood Park, New Jersey 07407

REFURBISHED PRODUCTS CARRY A SEPARATE WARRANTY, THIS WARRANTY DOES NOT APPLY. FOR DETAILS OF REFURBISHED PRODUCT WARRANTY, PLEASE REFER TO THE REFURBISHED PRODUCT WARRANTY INFORMATION PACKAGED WITH EACH REFURBISHED PRODUCT.

For customer use:
Enter below the Model No. and Serial No. which is located either on the rear, bottom or side of the cabinet. Retain this information for future reference.

Model No.: _____ Serial No.: _____

Purchase date: _____ Name of dealer: _____

HR-S9500U

JVC

JVC COMPANY OF AMERICA
DIVISION OF US JVC CORP.
41 Slater Drive, Elmwood Park, N.J. 07407

COPYRIGHT © 1998 VICTOR COMPANY OF JAPAN, LTD.

U Printed in Malaysia
0698 IYV*UN*PJ